

# TSMaster User Manual

TSMaster User Manual.....	1
Chapter 1 TSMaster User Interface.....	8
1.1 User Interface Introduction.....	8
1.1.1 Main Interface.....	8
1.1.2 Ribbon Functions .....	8
1.1.2.1 Analysis Tab.....	9
1.1.2.2 Hardware Tab .....	10
1.1.2.3 Project Tab .....	11
1.1.2.4 Tools Tab.....	13
1.1.3 Help Tab .....	14
1.1.4 Application Shortcuts.....	14
1.1.5 Univeral Drag and Drop.....	14
1.2 Channel Selection.....	17
1.3 System Messages Window.....	19
1.4 CAN / CAN FD Trace .....	21
1.4.1 Trace toolbar .....	21
1.4.2 Trace message identifier filter .....	23
1.4.3 Trace list columns.....	25
1.4.4 Trace Signals Display .....	26
1.4.5 Popup Menus .....	26
1.5 CAN / CAN FD Transmit Window .....	27
1.5.1 Transmit toolbar.....	28
1.5.2 Transmit list.....	29
1.5.3 Signals list.....	30
1.5.3.1 Signal Name .....	31
1.5.3.2 Signal Gen. ....	31
1.5.3.3 Generator .....	31
1.5.3.4 Raw Value.....	36
1.5.3.5 Raw Step .....	36
1.5.3.6 Physical Value.....	36
1.5.3.7 Phys Step.....	36
1.5.3.8 Comment .....	37

---

1.6 CAN Statistics .....	37
1.6.1 CAN Statistics list.....	37
1.6.2 CAN statistics popup menu .....	38
1.7 Graphics .....	38
1.7.1 Graphics toolbar.....	38
1.7.2 Graphics signal list.....	41
1.7.3 Signal property inspector.....	42
1.7.4 Signal Popup menu .....	43
1.8 CAN Database.....	44
1.8.1 CAN database toolbar .....	45
1.8.2 CAN database channel assignment.....	46
1.8.3 CAN Database field viewer.....	46
1.8.4 CAN element treeview .....	47
1.9 Hardware Configuration.....	47
1.9.1 Configuration Page.....	47
1.9.2 Channel configuration page .....	48
1.10 Bus Logging .....	49
1.10.1 Bus logging toolbar .....	49
1.10.2 Bus logging popup menu .....	49
1.11 Bus Playback.....	50
1.11.1 Bus playback toolbar .....	50
1.11.2 Bus playback popup menu.....	50
1.11.3 Playback control.....	51
1.12 Meter .....	51
1.12.1 Meter toolbar.....	52
1.12.2 Meter Layout Control.....	52
1.12.3 Meter signal editor .....	54
1.13 LIN Trace.....	55
1.13.1 Trace toolbar .....	55
1.13.2 Trace message identifier filter .....	57
1.13.3 Trace list columns.....	58
1.13.4 Trace Signals Display .....	59
1.13.5 Popup Menus.....	59
1.14 LIN Transmit .....	60
1.14.1 Transmit toolbar.....	61
1.14.2 LIN schedule table list .....	62
1.14.3 Transmit list.....	62
1.14.4 Signals list.....	63

---

1.14.4.1 Signal Name .....	63
1.14.4.2 Signal Gen. ....	63
1.14.4.3 Generator .....	64
1.14.4.4 Raw Value.....	64
1.14.4.5 Raw Step .....	64
1.14.4.6 Physical Value.....	64
1.14.4.7 Phys Step.....	64
1.14.4.8 Comment .....	65
1.15 LIN Database .....	65
1.15.1 LIN database toolbar .....	65
1.15.2 LIN database channel assignment .....	66
1.15.3 LIN element treeview.....	66
1.16 TS Channel Mapping .....	67
1.16.1 TS Channel Mapping toolbar .....	68
1.16.2 Hardware channel and application list .....	68
1.16.3 Map a hardware channel with a logical application channel .....	69
1.16.4 Add or delete an application.....	70
1.16.5 Set channel count of a bus type.....	70
1.17 Software Configuration .....	71
1.18 TS Log Converter .....	71
1.18.1 Log file types .....	72
1.18.2 Log converter interface .....	72
1.18.3 Mat File Example.....	73
1.19 CAN Remaining Bus Simulation.....	74
1.19.1 CAN RBS toolbar.....	75
1.19.2 CAN RBS message list.....	76
1.19.3 Modify Signal In CAN RBS .....	77
1.20 C Script Editor.....	77
1.20.1 C Script Editor toolbar .....	78
1.20.2 Symbol Tree.....	80
1.20.2.1 Program group .....	81
1.20.2.2 Code Generation .....	81
1.20.2.3 TSMaster Header .....	81
1.20.2.4 Database Header .....	82
1.20.2.5 Test Header .....	83
1.20.2.6 Global definition .....	84
1.20.2.7 Step Function .....	85
1.20.2.8 Documentation .....	86

---

1.20.2.9 Variables Group.....	87
1.20.2.10 Variable .....	87
1.20.2.11 Timers Group .....	88
1.20.2.12 Timer .....	89
1.20.2.13 On CAN Receive Event Group .....	89
1.20.2.14 On CAN Receive Event .....	90
1.20.2.15 On CAN FD Receive Event .....	91
1.20.2.16 On CAN Transmit Event Group.....	92
1.20.2.17 On CAN Transmit Event.....	92
1.20.2.18 On CAN FD Transmit Event.....	93
1.20.2.19 On CAN Pre-Transmit Event Group .....	93
1.20.2.20 On CAN Pre-Transmit Event .....	94
1.20.2.21 On CAN FD Pre-Transmit Event .....	95
1.20.2.22 On LIN Receive Event Group .....	95
1.20.2.23 On LIN Receive Event .....	96
1.20.2.24 On LIN Transmit Event Group.....	96
1.20.2.25 On LIN Transmit Event.....	97
1.20.2.26 On LIN Pre-Transmit Event Group.....	97
1.20.2.27 On LIN Pre-Transmit Event .....	98
1.20.2.28 On Var Change Event Group .....	98
1.20.2.29 On Var Change Event .....	98
1.20.2.30 On Timer Event Group .....	99
1.20.2.31 On Timer Event .....	99
1.20.2.32 On Start Event Group .....	100
1.20.2.33 On Start Event .....	100
1.20.2.34 On Stop Event Group .....	100
1.20.2.35 On Stop Event .....	101
1.20.2.36 On Shortcut Event Group.....	101
1.20.2.37 On Shortcut Event.....	102
1.20.2.38 Custom Functions Group .....	102
1.20.2.39 Custom Function .....	102
1.21 Application Window Host .....	103
1.22 Panel.....	105
1.22.1 Panel Toolbar .....	106
1.22.1.1 Panel Layout Settings .....	108
1.22.1.2 Panel Design Time Settings.....	108
1.22.2 Panel Controls .....	109
1.22.2.1 Panel Common Properties .....	109

---

1.22.2.1.1 Align .....	110
1.22.2.1.2 Enabled .....	113
1.22.2.1.3 Height.....	113
1.22.2.1.4 Margins .....	113
1.22.2.1.5 Opacity .....	114
1.22.2.1.6 Padding .....	114
1.22.2.1.7 Position .....	115
1.22.2.1.8 ReadOnly.....	115
1.22.2.1.9 RotationAngle .....	115
1.22.2.1.10 RotationCenter.....	115
1.22.2.1.11 Scale .....	116
1.22.2.1.12 VarLink .....	116
1.22.2.1.13 VarType .....	118
1.22.2.1.14 Width .....	118
1.22.2.1.15 TextSettings.....	119
1.22.2.2 Text.....	121
1.22.2.3 Image .....	123
1.22.2.4 Group Box .....	125
1.22.2.5 Panel.....	126
1.22.2.6 Path Button .....	129
1.22.2.7 Check Box.....	133
1.22.2.7.1 Track Bar.....	134
1.22.2.8 Scroll Bar .....	135
1.22.2.9 Input Output Box .....	135
1.22.2.10 Image Button .....	136
1.22.2.11 Selector .....	138
1.22.2.12 Button .....	140
1.22.2.13 Progress Bar .....	140
1.22.2.14 Radio Button .....	141
1.22.2.15 Start Stop Button .....	143
1.22.2.16 Switch.....	143
1.22.2.17 LED .....	144
1.22.2.18 Page Control.....	146
1.22.2.18.1 Page Control Properties .....	146
1.22.2.18.2 Delete a page in Page Control.....	147
1.22.2.19 Gauge .....	147
1.22.2.20 Graphics .....	150
1.22.2.21 Pie .....	151

---

1.22.3 Panel Design Recommendations .....	152
1.22.3.1 Using Shortcuts .....	152
1.22.3.2 Remaining Bus Simulation .....	152
1.23 Test System.....	152
1.23.1 Test System Toolbar .....	153
1.23.2 Test System Overview .....	154
1.23.3 Test System Login .....	154
1.23.4 System Configuration .....	156
1.23.5 DUT Configuration .....	156
1.23.6 Test Parameters.....	158
1.23.7 Test Cases .....	162
1.23.7.1 Test Cases Interface .....	162
1.23.7.2 Ordering of test cases .....	166
1.23.7.3 Test Case List Column.....	168
1.23.7.4 Test Case Code in Mini Program .....	169
1.23.8 Report Configuration .....	170
1.23.9 Test Execution .....	171
1.23.10 Test Logs.....	172
1.24 Mini Program Library .....	172
1.24.1 Mini Program Library Concept .....	172
1.24.2 Mini Program Library User Interface .....	173
1.24.3 Mini Program Library Popup Menu .....	174
1.25 Diagnostics .....	175
1.26 Calibration .....	175
1.26.1 Calibration Introduction.....	175
1.26.2 Calibration Data Types .....	175
1.27 System Variable Manager .....	176
1.27.1 System Variable Manager Introduction .....	176
1.27.2 Toolbar of System Variable Manager .....	177
1.27.3 Popup Menu of System Variables .....	180
1.27.4 Working with System Variables.....	180
1.28 Measurement Setup .....	181
1.28.1 Measurement Setup Toolbar .....	182
1.28.2 Measurement Setup Popup Menu .....	183
1.28.3 Working with Measurement Setup.....	185
1.28.3.1 Measurement Setup Node State .....	185
1.28.3.2 Measurement Windows Filter Capabilities.....	187
1.29 Measurement Filter .....	188

---

1.29.1 Measurement Filter Toolbar .....	189
1.29.2 Measurement Filter Popup Menu .....	193
1.29.3 Filter List Operation .....	195
1.30 Document.....	195
1.30.1 Document Toolbar .....	196
1.30.2 Document Area .....	196
1.30.3 Document Popup Menu.....	196
1.31 LIN Remaining Bus Simulation .....	197
1.32 Automotive File Converter .....	198
1.32.1 Automotive File Converter Toolbar.....	198
1.32.2 Supported input files .....	199
1.32.3 Supported output files.....	199
1.32.4 Steps to Convert Database Files.....	200
1.32.5 Steps to Convert dbc file to C Code .....	202
1.33 Symbol Mapping .....	203
1.34 Stimulation .....	203
1.35 Calibration Curve.....	203
1.36 Video Replay.....	203
1.37 Excel Test Module .....	203
Chapter 2 TSMaster Help Files .....	205
2.1 Help Content .....	205

## Chapter 1 TSMaster User Interface

### 1.1 User Interface Introduction

TSMaster is an open environment for monitoring, simulation of automotive network communications. The main interface of TSMaster is shown as below.

#### 1.1.1 Main Interface




Fig 1 TSMaster main interface

1. Application title bar. The application name, build time and loaded configuration is shown in this title bar.
2. Ribbon toolbar. The main functions are accessed from this ribbon toolbar.
3. Page tabs. Each tab contains a set of windows for measurement and simulation. User can add or delete window inside the current tab.
4. Application forms. Each window is a function performing specific tasks.
5. Add page button. User can add new page by clicking this button. If user want to delete a page, just right-click on the current page and select “delete tab” command.
6. Status bar. The connection status of application, logging information and write information are shown in the status bar.

#### 1.1.2 Ribbon Functions

There are four tabs in ribbon: Analysis, Hardware, Tools and Help.



### 1.1.2.1 Analysis Tab




Fig 2 Analysis tab in Ribbon

**Start:** Start application. This operation will connect all the logical channels with hardware channels, the data from hardware will be shown in the application interface.

After application is started, the following functions are not available:

- Bus Replay. Bus replay is only allowed when application is disconnected.
- Channel Selection. Channel selection is only available before application connection.
- Channel Mapping. Channel mapping information is required before application is connectd.
- Network Hardware. Hardware parameters are only allowed to configure before application is started.

**Stop:** Stop application. This operation will disconnect all the logical channels with hardware channels. The logging operation is also stopped if already running.

After application is stopped, the following functions are now available:

- Bus Replay. User can load logged files and analyze them in the application forms.
- Channel Selection. User can map channels freely when application is not connected.
- Channel Mapping. User can manage application and channels in the channel mapping form.
- Network Hardware. User can alter hardware configuration when application is not connected.

**Messages:** Show message window.

**Trace:** This is a drop-down button as shown below:




Fig 3 Trace drop-down button

1. Trace windows that already exist in the system, click to show one of them.
2. Add new trace window in the system. The default location is the current tab.

**Transmit:** Show or add transmit windows for bus message transmission.

**Graphics:** Show or add graphics windows for signal curve display.

**Gauges:** Show or add gauge windows for signal value display.

**Statistics:** Show bus statistics window.

**Database:** Show bus database window, CAN (\*.dbc) and LIN (\*.ldf) files are supported.

**Start Logging:** Start logging of bus events.

**Stop Logging:** Stop logging of bus events.

**Bus Logger:** Show bus logging configuration window.

**Bus Replay:** Show bus replay window.

**Log Converter:** Show log file converter application which converts blf file format to asc file format and vice versa.

**Log Directory:** Show the current log file directory in Windows explorer.

### 1.1.2.2 Hardware Tab




Fig 4 Hardware tab in ribbon

**Channel Selection:** Open channel selection window for logical channel mapping

with hardware channels.

**Channel Mapping:** Open channel mapping configuration window to manage application logical channels and mapping.

**Network Hardware:** Open hardware configuration window to configure individual hardware channel parameters.

**Turbo Mode:** Checking this option will minimize all hardware channel latencies at the expense of consuming more CPU usage. Users who concern very much for hardware performance are recommended to check this option.

### 1.1.2.3 Project Tab




Fig 5 TSMaster Project Tab

**Load:** Load TSMaster configuration file, this operation will overwrite all the current settings.

**Save:** Save TSMaster configuration file to a location. If the destination configuration is specified, the following save command will update the destination configuration file.

The first time when the button is clicked, a save as dialog will be prompt for user to select a destination configuration file:




Fig 6 Save configuration for the first time

Just specify a location and file name for the configuration file, and click “Save” button. The application title will display the destination configuration file name after the configuration file is saved:




Fig 7 Configuration file name shown in the title bar

After the configuration file is saved, each successive save command will update this file continuously.

**Save as:** This command will popup a save as dialog for the user to change the configuration file to another location.

**New:** This command will erase all the current configuration and create a new environment for analysis. Note: please save all your work into a configuration file before applying this command.

**Settings:** Opens a software configuration window showing all the opened windows. User can show/hide/delete the application forms in this window. The title of each application form can also be modified here.

**Tabbed Windows:** This checkbox displays all windows in tabs or vice versa:




Fig 8 Tabbed Windows

**Note:** When this checkbox is checked, the lower tab group disappears because all the sub forms are displayed in the above tabs.

If this checkbox is unchecked, the lower tab group will be visible again and each tab group controls a series of sub mdi forms.

**Cascade:** Cascade application forms in the current tab group.

**Tile Horizontally:** Tile all the application forms in the current tab horizontally.

**Tile Vertically:** Tile all the application forms in the current tab vertically.

**Note:** This above features “Cascade, Tile Horizontally and Tile Vertically” are only available when “Tabbed Windows” feature is unchecked.

#### 1.1.2.4 Tools Tab




Fig 9 Tools tab in ribbon

**Hexadecimal Display:** This command toggles display between hexadecimal and decimal.

**Symbol Display:** This command toggles display between symbol description and value of a signal in database.

**C Code Editor:** This command opens TSMaster C Code Editor for editing C scripts.

**Python Code Editor:** This command opens TSMaster Python Code Editor for editing Python scripts.

**Python Console:** This will open python console window for interacting with internal python engine shipped with TSMaster.

### 1.1.3 Help Tab




Fig 10 Help tab in ribbon

**Software Manual:** This software manual will be shown.

**Software SDK:** TSMaster API description manual will be shown.

**Release Note:** This will open release note for the current version of TSMaster.

**About...:** This will show about dialog of TOSUN company.

### 1.1.4 Application Shortcuts

- Ctrl + O: Open project
- Ctrl + N: Create new project
- Ctrl + S: Save the current project
- Ctrl + TAB: move to next tab in Tabbed windows mode
- Ctrl + Shift + TAB: move to previous tab in Tabbed windows mode
- Ctrl + W: close the current active window or tab

### 1.1.5 Universal Drag and Drop

TSMaster support many different automotive bus database types to be dragged and dropped into TSMaster application main interface.




Fig 11 Universal drag and drop in TSMaster

The supported suffixes of file types are listed below:

Table 1 File formats that support drag and drop

File extension	Associated Vendor	File Description
<b>blf</b>	Vector	Binary logging format of different bus systems
<b>dbc</b>	Vector	CANdb network file
<b>ldf</b>	ISO	LIN description file
<b>mpc</b>	TOSUN	TSMaster mini program source file extension
<b>t7z</b>	TOSUN	TSMaster project file
<b>mp</b>	TOSUN	TSMaster mini program compiled binary file
<b>arxml</b>	AutoSAR	AutoSAR system description file
<b>dbf</b>	ETAS	Bus Master file format
<b>sym</b>	PEAK	PEAK PCAN CAN description file
<b>mat</b>	Mathworks	MATLAB file format used in TOSUN calibration module

<b>mp4</b>	MPEG-4 Part 14	ISO/IEC 14496-12(MPEG-4 Part 12 ISO base media file format), used in Video Replay
<b>avi</b>	Microsoft	Audio Video Interleave, a widely used video file format created by Microsoft in 1992, used in Video Replay
<b>wmv</b>	Microsoft	A video file based on the Microsoft Advanced Systems Format (ASF) container format, used in Video Replay
<b>mpeg</b>	ISO and IEC	Moving Picture Experts Group (MPEG), used in Video Replay, used in Video Replay
<b>mpg</b>	ISO and IEC	Moving Picture Experts Group (MPEG), used in Video Replay, used in Video Replay
<b>m4v</b>	Apple	A video container format developed by Apple and is very similar to the MP4 format, used in Video Replay
<b>mov</b>	Apple	A movie file saved in the QuickTime File Format (QTFF), which is a multimedia container file format, used in Video Replay
<b>asf</b>	Microsoft	The container format for Windows Media Audio and Windows Media Video-based content, used in Video Replay
<b>flv</b>	Adobe	A file format used by Adobe Flash Player and Adobe AIR to store and deliver synchronized audio and video streams over the Internet, used in Video Replay
<b>f4v</b>	Apple	A Flash MP4 Video file, sometimes called an MPEG-4 Video file, used in Video Replay
<b>rmvb</b>	RealNetworks	RealMedia Variable Bitrate (RMVB) is a variable bitrate extension of the RealMedia multimedia



		digital container format, used in Video Replay
<b>rm</b>	RealNetworks	RealMedia is a proprietary multimedia container format created by RealNetworks. Its extension is ". rm", used in Video Replay
<b>3gp</b>	3rd Generation Partnership Project	A 3GP file is a multimedia file saved in an audio and video container format, used in Video Replay
<b>vob</b>	DVD Forum	A movie data file from a DVD disc, typically stored in the VIDEO_TS folder at the root of the DVD, used in Video Replay

## 1.2 Channel Selection










Fig 12 Channel Selection dialog

Channel selection dialog is used to quick configure application channel mapping before application is running.

1. **Toolbar buttons described below:**
  - Activate All:** Activate all the application channels
  - Deactivate All:** Deactivate all the application channels
  - Refresh Hardware:** Refresh hardware channel list after USB devices are plugged in or out
  - Auto Mapping:** Automatically search hardware channels and map each application channel with available hardware channel in the order of discovery.
2. **Application CAN channel count:** Displays the current CAN channel count of TSMaster, the user can change it using drop-down button, the modification takes effect immediately.
3. **Application LIN channel count:** Displays the current LIN channel count of TSMaster, the user can change it using drop-down button, the modification takes effect immediately.
4. **Availability:** Indicates the availability of the current application channel. The color of the icon has the following meaning:
  -  This application channel mapping is valid. The corresponding application is fully functional during measurement.
  -  This application channel is disabled. The corresponding application channel is not available during measurement.
  -  This application channel is invalid, the user must resolve the mapping problem, otherwise the application cannot start.
5. **Application channel:** Application logical channel specified by user. Each application channel number has an ascending order starting from 1. The available application channels are from 1 to CAN channel count.
6. **Active Selection:** This checkbox controls the availability of the current application channel. Default selection is checked. If user wants to disable the current application channel, the selection can be unchecked. After that, the mapping of this application channel will not be available during measurement.

7. **Hardware channel selection drop-down box:** This drop-down box lists all the available hardware channels that can be mapped with the current application channel. The color of each item listed has the following meaning:
-  This hardware channel is not mapped with other application channels, it is free for user to select.
  -  This hardware channel is already mapped with one application channel. Multiple application channels mapping to the same hardware channel is not allowed.
  -  This application channel is not mapped with any hardware channel, the user must ensure the mapping of the application channel before measurement starts.

Note: If TSMaster is opened for the first time, when user tries to connect application without opening this dialog, a default configuration is automatically applied, which performs the following operations:






[1] search for available CAN and LIN hardware channels excluding TS virtual channels

[2] set application CAN and LIN channels according to the first found hardware channels

[3] start application for the measurement

### 1.3 System Messages Window

System messages window displays all the software related messages, the message color has the following meaning:

-  Default: Normal message
-  Verbose: Message of minor importance
-  Hint: Message that should to come into notice
-  OK: Message that indicates the current operation is successful
-  Error: The current operation encounters an error

The description of system message window is shown below:











Fig 13 System Message Window


### 1. Toolbar buttons

-  Pause checkbox, check to suppress the display of incoming messages
-  Copy the selected logs into clipboard
-  Copy all the logs into clipboard
-  Clear the display of the current window, this will delete all the logs
-  Save the log to a file on the disk
-  Debugging mode switch, check to open debug mode, each log message will

then contain stack trace info.

### 2. Common window buttons

-  Opens help document for the current window

✘ Delete or hide the current window, if the user selects “Delete”, the window will be destroyed and will not appear in any of the application tabs; if the user selects “Hide”, the window will be hidden in the current tab, but may be displayed in other tabs. Note: the default operation of closing a window by clicking on the right-top red button of a window  is to hide it.

3. **Logging area:** The time and description of events are displayed here.

## 1.4 CAN / CAN FD Trace

CAN / CAN FD Trace window display events from CAN / CAN FD networks.







Fig 14 CAN / CAN FD Trace Window


### 1.4.1 Trace toolbar


|| Pause display button, when checked, the “Pause” button will switch to “Continue”  and incoming events will not be refreshed on the screen. The incoming events will be visible again when the “Continue” button is clicked.


✘ Clear the display of the current trace window.

 This checkbox sets trace window in chronological view mode. In this mode every incoming new message will be display as one trace line.

 This checkbox sets trace window in relative time mode.

 This checkbox ensures the trace list always scroll to the latest message.

 Expand all message nodes to view their signal values.

 Collapse all message nodes so signals are hidden.

Filter String: speed  Filter trace list with specified string, the filter string can be the following types:




Fig 15 Filter by identifier




Fig 16 Filter by signal name




Fig 17 Filter by message name




Fig 18 Filter by signal symbol value




Fig 19 Filter by signal numeric value

Clear filter value, the trace list will then display all the trace lines.

Message filter tool, which allows specific message identifiers to display in the trace, and meanwhile blocks other message identifiers. User can use this message filter to hide some irrelevant messages, or just monitor certain messages.

### 1.4.2 Trace message identifier filter




Fig 20 Trace message identifier filter

The trace message identifier filter works under either of the two conditions:

1. Block mode Block

The message identifier in the list will be blocked, and other message will pass the filter. In the above picture, only 0x123 will be blocked, while other message identifiers will be displayed in the trace window.

2. Pass mode Block

The message identifier in the list will be passed, and other message will be blocked. In the following picture, only 0x123 will be refreshed in the trace list:




Fig 21 Message identifier filter working in pass mode

To add or delete message identifiers in the list, just right-click on the empty area of the list, you will see the following popup menu items:






Fig 22 Add or delete message identifiers in the list




Add CAN frame identifiers from database

or on the fly. These added message identifiers will be passed to the trace list. These menu items will be shown when the filter is in pass mode.



Add CAN frame identifiers from database or


on the fly. These added message identifiers will be blocked and will not be displayed in the trace list. These menu items will be shown when the filter is in block mode.



This operation will remove the selected message identifier


from the filter list.





Clear all

This operation clears all the message identifier items from the filter list.



Filter Enabled

This checkbox controls whether the message identifier filter is enabled or not.

### 1.4.3 Trace list columns

**Absolute Time:** Absolute measurement time in seconds, this is the default time display format. The absolute time or message will be displayed in this column.

**Relative Time:** The relative time indicates the time in relation to the preceding message. In chronological mode this is the message received directly before the current message, whereas in fixed position mode the relative time is displayed in relation to the previous message of the same type.

**Chn:** The channel number of the message.

**Identifier:** CAN message identifier, extended identifier format will add a “x” symbol to the identifier value.

**FPS:** Frames per second, this column displays the frame rate of specific identifier.

**Message Name:** The name of the message defined in the database.

**Type:** CAN message type will be displayed here including the following:

- Data: Classical CAN data frame
- Remote: Classical CAN remote frame
- FD: CAN FD frame

**Dir:** Direction of the CAN message, can be Tx (transmit) or Rx (receive)

**DLC:** Data length code from CAN messages, in CAN FD frame the DLC has the following relationships with the length of data bytes:

DLC	Data length
0~8	Same as DLC
9	12
10	16

11	20
12	24
13	32
14	48
15	64

**Data Len:** The length of data bytes.

**Message Data Bytes:** Each data byte of the message. In CAN FD frame, the data byte can be larger than 8 bytes, each data byte with index starting from 0 is shown:

```

Message Data Bytes 07 08 09 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26
01 02 03 04 05 06 07 08 05 37 FF FF FF 80 76 09 00 46 57 FF FF FF FF 23 00 00 00
    
```

Fig 23 Message data bytes with index starting from 0

### 1.4.4 Trace Signals Display

Trace signals can be expanded if a message is defined in the loaded CAN database:




Fig 24 Signals with updated values highlighted

### 1.4.5 Popup Menus

Most of trace popup menu items can be found in trace toolbar except “Copy” and “Block selected message”:




Fig 25 Trace popup menu

To copy the trace lines, the user has to select certain trace lines and then click the “Copy” item. The selected text has the same layout as trace display:

无标题 - 记事本

文件(F) 编辑(E) 格式(O) 查看(V) 帮助(H)

	Absolute Time	Chn	Identifier	FPS	Message Name	Type	Dir	DLC	Data Len.	Message Data
[+]	1027.082942	2	064	10	EngineData	FD	Rx	15	64	01 02 03 04 (
			EngKnocking	0						
			EngIgnitionAngle	0						
			EngStates	0						
			EngValvePos	0						
			EngTubePressure	0						
			SleepInd	0						
			ShiftRequest		Shift_Request_Off					
			Gear		Idle					
			EcoMode	1						
			EngTorque	2.59407338535435E18						
			EngSpeed	593 rpm						
			EngForce	5 N						
			PetrolLevel	4 l						
			EngPower	20.55 kW						
			IdleRunning		Running					
			EngTemp	-44 degC						
[+]	1027.082942	1	064	10	EngineData	FD	Tx	15	64	01 02 03 04 (

Fig 26 Selected trace lines in text

## 1.5 CAN / CAN FD Transmit Window

CAN / CAN FD frames can be transmitted manually or periodically by CAN / CAN FD transmit window:




Fig 27 CAN / CAN FD Transmit Window

### 1.5.1 Transmit toolbar

- Add a CAN message from database.
- Add a raw CAN message directly into transmit list, which can be freely modified.
- Copy selected CAN messages into clipboard, which can be pasted into current transmit list.
- Paste the copied CAN message from clipboard into the current transmit list.
- Delete the selected CAN messages from current list
- Remove all the CAN messages from current list.
- Save the current transmit list to an external file. For the first time a save dialog box appears for the user to specify destination file. The following save operations will overwrite this file.
- Export the current transmit list to an external file.
- Load transmit list from external file, this operation will overwrite all the existing transmit list.


- ▶ Start the transmission of the current transmit list. Note: this operation will send all the frames inside the transmit list, for manual transmit messages, only one frame is sent per message; for cyclic transmit messages, all of them are scheduled to be sent periodically.
- Stop all the periodically transmitted messages. Note: this operation will be executed everytime when application disconnects.

## 1.5.2 Transmit list

The transmit list contains messages to be edited, each message has the following properties:

**Row:** The number of each transmit message in ascending order, this field is read-only and cannot be edited.

**Send:** This is a button controlling the current message transmission. The style of this button depends on the trigger type of the current message:

- Manual transmit message: Each click on this button will trigger one CAN message transmission.
- Periodic transmit message: The first click on this button will start the cyclic transmission of this message. The transmit button will then switch to a “Stop” button:  The next click on this stop button will stop the cyclic transmission of the current message.

**Trigger:** Message transmission type:

- Manual: One click on the “Send” button will trigger one CAN message transmission
- Periodic: Periodic transmission type has the following properties:




Fig 28 Periodic transmission type configuration

The period can be within range from 1ms to 1000000000ms.

**Message Name:** The name of the message, if this message is added from CAN

database, then the message name is defined by CAN database and cannot be modified by user; if this message is added manually, then the name of the message can be freely altered by user.

**Id:** Identifier of CAN message.

**Chn:** The channel number of CAN message.

**Type:** CAN frame type, can be the one of the following 6 types:

- Std. Data: Classical CAN data frame with standard identifier
- Std. Remote: Classical CAN remote frame with standard identifier
- Std. FD: FD frame with standard identifier
- Ext. Data: Classical CAN data frame with extended identifier
- Ext. Remote: Classical CAN remote frame with extended identifier
- Ext. FD: FD frame with extended identifier

**DLC:** Data length code of the CAN message, which can be within range 0~15.

**D0~D7:** Classical CAN data frame data byte editors. Note: In FD CAN frame, these editors are unavailable and replaced by “Raw Data” editors located on the bottom panel.

### 1.5.3 Signals list

Signals list displays editors for modifying signal properties of the selected CAN message defined in CAN database. The raw CAN messages do not have signals list editors.

Signal Name	Signal Gen.	Generator	Raw Value	Raw Step	Physical Value	Phys Step	Comment
EngTubePressure	▶ ■ ⚙	None	0	6666666666666666	0	107374182.35	
SleepInd	▶ ■ ⚙	None	0	1	0	1	
ShiftRequest	▶ ■ ⚙	None	0	1	[0] Shift_Request_Off	1	
Gear	▶ ■ ⚙	None	0	1	[0] Idle	1	
EcoMode	▶ ■ ⚙	None	1	1	1	1	
EngTorque	▶ ■ ⚙	None	23FFFFFFFF574600	6666666666666666	2.59407338535435E18	107374182.35	
EngSpeed	▶ ■ ⚙	Sine	7FFF	666	-32513	3276.75	
EngForce	▶ ■ ⚙	None	40A00000	CCCCCCCC	5	214748364.75	
PetrolLevel	▶ ■ ⚙	None	4	C	4	12.75	
EngPower	▶ ■ ⚙	None	807	CCC	20.55	7.5	
IdleRunning	▶ ■ ⚙	None	0	1	[0] Running	1	
EngTemp	▶ ■ ⚙	None	3	6	-44	10	




Fig 29 Signals list of the selected CAN message

### 1.5.3.1 Signal Name

The signal name defined in the CAN database.

### 1.5.3.2 Signal Gen.

The signal value generator feature, which has three buttons for sending and configuring the value changing behavior of each CAN signal:

-  Start generating of the current signal. Once this button is clicked, the button changes to “Pause” button shown below.
-  Pause button, once this button is clicked, the current CAN signal generator pauses, the button then changes back to “Send” button shown above.
-  Stop button, a click on this button stop the operation of the current CAN signal generator.

### 1.5.3.3 Generator

This combobox specifies the generator type of the current CAN signal, which has the following choices:

- None: No CAN signal generator is available, the signal value in the sent CAN message depends on the physical value set on the “Physical Value” on the right side.
- Ramps and Pulses:




Fig 30 Ramps and Pulses signal generator

The selected CAN signal will be generated in the time series of Rise-Hold-Fall-Delay. The high value, low value and each time segment can be modified.

- **DB Min and Max:** The minimum and maximum value defined in the database.
- **Phy Min and Max:** The physical minimum and maximum value that the signal can reach.
- **Periodic Generation:** The signal generator can restart itself when a period of value has been generated.
- **Repeat Limit:** The restart count of periodic generation, if not specified, the restart count of periodic generation is unlimited. This limit number depends on the activation status of “Periodic Generation”.
- **Auto Start On Message Transmission:** The signal generator will automatically start when the parent message is scheduled to be transmitted periodically.
- **Signal Value table:** The signal value table defines each signal physical value against time in milliseconds. The table is read-only except custom signal generator.
- **Parameter list:** The signal waveform depends the parameters defined in this table.



- Signal waveform preview: The signal value being generated by this generator can be previewed in a time-value view here.

- Value Range




Fig 31 Value range signal generator

The value range generator traverses the signal value in “Rising”, “Falling” and “Alternate” methods.

- Toggle




Fig 32 Toggle signal generator

The toggle signal generator changes the signal value between low and high. The low and high value can be specified by the user.

#### ■ Random




Fig 33 Random signal generator

The random signal generator outputs random signal values. The low value and high value of the random range can be specified.

#### ■ User Defined




Fig 34 User defined signal generator

User defined signal generator provides an interface for the user to interact with the signal values. The user can make the waveform from external software such as excel, and then import the waveform data into the transmission value table.

1. **Signal Value table:** To append a new value into the table, press “Down” key. To insert a new value before the selected value in the table, press “Insert” key. Note: the time series in the table must be in ascending order, otherwise the generator will stop on the incorrect time.
2. **Import button:** The user can import signal waveform defined externally. The waveform data file should have the extension of “\*.sig” and should have the following format:

```

1 Interpolation;Linear
2 Sample rate [ms];10
3 Delay [ms];0
4 Time [ms];EngPower
5 0;0
6 10;80
7 20;10
8 200;555
9 2000;12
10 4000;600
11

```

Fig 35 User defined signal generator import file format

Line 1: Interpolation method, only Linear is supported currently.

Line 2: Sample rate in milliseconds. Note: the character “;” is the separator between the key and value in the “key - value” pair.

Line 3: Delay time in milliseconds.


Line 4: Table description of the following “key - value” pair.

Line 5 and the following: Table data defined in “key - value” pair which are separated by “;” character.

3. **Export button:** The export feature of the signal generator, which will export the current table value into a “\*.sig” file.

#### 1.5.3.4 Raw Value

Raw value editor of the current selected signal. To modify a signal’s raw value without touching its physical value, use this editor.


 Increment and decrement button of the raw value. Clicking on the corresponding button increments or decrements the raw value by the step defined on the “Raw Step” field.

#### 1.5.3.5 Raw Step

The increment or decrement step of the “Raw Value” field.

#### 1.5.3.6 Physical Value

Physical value editor of the current selected signal. To modify a signal’s physical value without touching its raw value, use this editor.

 Increment and decrement button of the physical value. Clicking on the corresponding button increments or decrements the physical value by the step defined on the “Phys Step” field.

#### 1.5.3.7 Phys Step


The increment or decrement step of the “Physical Value” field.

### 1.5.3.8 Comment

User comment on the specified signal.

## 1.6 CAN Statistics

### 1.6.1 CAN Statistics list



Statistics	Channel 1	Channel 2
BusLoad [%]	2.52	2.52
PeakLoad [%]	2.52	2.52
Std. Data [fr/s]	211	211
Std. Data [total]	9238	9238
Ext. Data [fr/s]	0	0
Ext. Data [total]	0	0
Std. Remote [fr/s]	0	0
Std. Remote [total]	0	0
Ext. Remote [fr/s]	0	0
Ext. Remote [total]	0	0
Error Frames [fr/s]	0	0
Error Frames [total]	0	0

Fig 36 CAN Statistics

CAN Statistics window displays bus load and frame rate of each CAN channel. The following value can be monitored:

Bus Load: CAN bus load in percentage.

Peak Load: CAN bus peak load from the start of measurement in percentage.

Std. Data [fr / s]: Standard classical CAN data frame rate per second.

Std. Data [total]: Total number of classical standard CAN data frame.

Ext. Data [fr / s]: Extended classical CAN data frame rate per second.

Ext. Data [total]: Total number of classical extended CAN data frame.

Std. Remote [fr / s]: Standard classical CAN remote frame rate per second.

Std. Remote [total]: Total number of remote classical CAN remote frame.

Ext. Remote [fr / s]: Extended classical CAN remote frame rate per second.

Ext. Remote [total]: Total number of extended classical CAN remote frame.

Error frames [fr / s]: CAN error frame rate per second.

Error frames [total]: Total number of CAN error frames.

## 1.6.2 CAN statistics popup menu




Fig 37 CAN statistics popup menu

Clear Statistics: Clear all the statistics data immediately.

Pause: Pause the display of current CAN statistics data.

## 1.7 Graphics

Graphics window displays signals from CAN, CAN FD and LIN messages.







Fig 38 Graphics

### 1.7.1 Graphics toolbar

 Pause the display of graphics, the next click on this button will resume the display of graphics.

 This checkbox controls the display of left signal list panel.

 Absolute time and relative time switch box, when enabled, the time axis in the graphics will switch to a formatted date time display:











Fig 39 Formatted date time display of time axis

When disabled, the time axis will display relative time relative to the beginning of measurement.

-  Zoom in button, click to zoom in the graphic display in time.
-  Zoom out button, click to zoom out the graphic display in time.
-  Zoom reset button, click to set the graphics display to original zoom factor.
-  Add a CAN signal from database.
-  Add a LIN signal from database.
-  Delete the selected signal in the list.
-  This checkbox displays or hides the measurement cursor. When this checkbox is checked, a measurement cursor will be displayed on the graphics window, which displays the selected signal value according to the measurement time. Move the cursor across the graphic area, you will see the value displayed in the measurement cursor being continuously updated. Uncheck this checkbox hides the measurement cursor.





Fig 40 Graphics measurement cursor

 Time measurement cursor checkbox. This checkbox shows or hides the time measurement cursor pair.





Fig 41 Time measurement cursor checkbox

When the time measurement cursor is enabled, the user can define a time range between blue cursor and red cursor. “Left click” on the graphics window drops a blue cursor to the location of the click point, and “Right click” on the graphics window drops a red cursor to the location of the click point. The delta time between blue cursor and red cursor will then be displayed on the bottom area of time axis in the graphics window.

 Sample point display. When this checkbox is checked, each sample point will be displayed in the graphics window, it is easy for the user to detect frame loss situation with the help of the same point display.









Fig 42 Sample point display

 Export graphics data to an external location. Note: this button is only enabled when application disconnects.

 Import graphics data from an external location. Note: this button is only enabled when application disconnects.

 Clears all the data in the graphics.

### 1.7.2 Graphics signal list



		Name	Value
<input checked="" type="checkbox"/>	<input type="checkbox"/>	ShiftRequest	hift_Request_Of
<input checked="" type="checkbox"/>	<input type="checkbox"/>	EngTemp	-44.00
<input checked="" type="checkbox"/>	<input type="checkbox"/>	EngPower	102.50
<input checked="" type="checkbox"/>	<input type="checkbox"/>	EngSpeed	6755.00

Fig 43 Graphics signal list

Signal visibility checkbox, the signal will be set to hidden when this checkbox is unchecked.

Always show value axis checkbox, if the checkbox is checked, the value axis of the specified signal will be displayed in the graphics window permanently.





Fig 44 Signal axis display

 Color picker. Clicking on this button will popup a dialogbox for the user to pick a color for the specified signal:





Fig 45 Color picker of graphic signals

 Signal name field, this field displays signal name according to the database definition.

 Signal value field, this field display real-time signal physical value.

### 1.7.3 Signal property inspector

Signal property inspector will be popued when the signal in the list is double-clicked, or the “Edit Signal...” menu item is clicked. Take “CAN signal property inspector” as an example:

CAN Signal Parameter	Value
Name	EngTemp
Length	7
Byte Order	Intel
Value Type	Unsigned
Minimum	-50
Maximum	204
Unit	degC
Factor	2
Offset	-50
Init. Value	0
Comment	
Start Bit	16
Message ID	64

Fig 46 Signal properties inspector

The following properties can be displayed or modified by user freely:

Name: the signal name

Length: the bit count of the signal

Byte Order: Intel or Motorola byte order switch of the signal

Value Type: the value type can be Unsigned, Signed, 32-bit float or 64-bit float

Minimum: the minimum physical value of the signal, this value also adjusts the lower range of graphics display

Maximum: the maximum physical value of the signal, this value also adjusts the higher range of graphics display

Unit: the unit of the signal

Factor: enlarge factor of the signal

Offset: offset value of the signal

Init. Value: initialize value of the signal

Comment: the user can add comments on the specified signal

Start Bit: the signal start bit in the message which contains it

Message ID: the identifier of the message which contains it

Channel Number: the CAN channel number of the signal

#### 1.7.4 Signal Popup menu




Fig 47 Graphics signal popup menu

Check selected: Make all the selected signals visible in the graphics.

Uncheck selected: Make all the selected signals invisible in the graphics.

Check All: Make all the signals visible in the graphics.

Uncheck All: Make all the signals invisible in the graphics.

Add CAN signal from database...: This button popup a CAN database signal selector for the user to select CAN signals to monitor.

Add LIN signal from database...: This button popup a LIN database signal selector for the user to select LIN signals to monitor.

Add user defined signal...: This button adds a custom signal in the list, which can be modified later.

Edit Signal...: Pops up the “Signal property inspector” as described above.

Delete Signal: This button deletes all the selected signals from the list.

Clear All Signals: This button deletes all the signals from the list.

Pause Graphics: This button pauses the display of the current graphics window, a click on this button again will resume the display of the current graphics window.

## 1.8 CAN Database

CAN database viewer can be used to load/unload CAN database, select CAN messages or CAN signals in the TSMaster application.




Fig 48 CAN Database

### 1.8.1 CAN database toolbar



Add a CAN database from external \*.dbc file



Edit the current selected database (\*.dbc file) using default editor on this computer



Delete the current selected database from the database list



Delete all the database links from the database list



Increase a channel resource for database file mapping



Decrease a channel resource for database file mapping



Expand all nodes in the database treeview



Collapse all nodes in the database treeview

Filter by: database element filter, can be the following for user to select in database element selector mode:

- Show All: all the database elements will be displayed in the treeview
- CAN Signal: Only CAN signals are displayed

- CAN Message: Only CAN messages are displayed
- CAN Node: Only CAN nodes are displayed
- Environment Variable: Only environment variables are displayed

### 1.8.2 CAN database channel assignment

CAN database channel assignment enables the user to associate the selected database with specific CAN channels. A CAN database can support only one CAN channel, or multiple channels.




Fig 49 Channel assignment

When there are multiple database files loaded, the user may right-click on the specific CAN channel, which pops up a list of available CAN databases. The user can associate / deassociate the database with the currently selected CAN channel by clicking on the database item in the popup menu.

### 1.8.3 CAN Database field viewer

Database Field	Definition	
Value Type	Signed	▼
Minimum	0	▼
Maximum	0	▼
Unit		
Factor	1	▼
Offset	0	▼
Init. Value	0	▼

Fig 50 CAN database field viewer

The CAN database field viewer is used to display properties of the selected element, which can be CAN signal, CAN message, CAN node, environment variable or

CAN network.

Note: the CAN database field viewer currently not supports editing of CAN elements.

### 1.8.4 CAN element treeview




Fig 51 CAN element treeview

The CAN element treeview displays all the loaded CAN database information including CAN network, CAN signals, CAN messages, CAN nodes and Environment variables.

## 1.9 Hardware Configuration

The hardware configuration window is used to set hardware parameters before measurement starts.

### 1.9.1 Configuration Page

The configuration page contains all the application channels specified by user. There is a button which opens channel selection dialog mentioned above.




Fig 52 Hardware Configuration page

### 1.9.2 Channel configuration page

The channel configuration page differs when different application channel is selected. The user must check the hardware settings in each channel before starting the measurement.




Fig 53 Hardware channel settings



## 1.10 Bus Logging








Fig 54 Bus logging


### 1.10.1 Bus logging toolbar

- ▶ Start logging, this button is disabled when logging engine is working.
- || Pause logging, this button is enabled when logging engine is working.
- Stop logging, this button is enabled when logging engine is working.

Log File: C:\Projects\TOSUN\Projects\TSMa:    Log file destination editor.

 Select log file location.

 Opens folder of log file destination.

 Starts TS log file converter to convert log files to another format.

**Default path** Default path checkbox, if this checkbox is checked, the log file destination folder will be set to relative folder to TSMaster configuration file.

**Add timestamp** Auto add timestamp to every log file name.

### 1.10.2 Bus logging popup menu




Fig 55 Bus logging popup menu

The popup menu will popups when user right-click on the log file list. All the menu items are described in the above chapter.

## 1.11 Bus Playback

Bus playback window replays CAN, CAN FD and LIN messages from external log files when the application is not connected.










Fig 56 Bus playback

### 1.11.1 Bus playback toolbar

-  Starts playback. This button is not enabled when application is connected.
-  Pause playback. This button is enabled when playback starts.
-  Stop playback. This button is enabled when playback starts.
-  Add playback files to the log file list.
-  Remove the selected log files from the list.
-  Remove all the log files from the list.

### 1.11.2 Bus playback popup menu




Fig 57 Bus playback popup menu

The menu items are described in the above chapter except:

Open containing folder...: Open the folder which contains the selected log file.

Rename...: Pops up a rename dialog box for the user to rename the selected log file.

### 1.11.3 Playback control





Fig 58 Bus playback control

 Playback progress indication.

 Playback range selection.

## 1.12 Meter

Meter displays CAN or LIN signals defined in CAN or LIN databases.






Fig 59 Meter

### 1.12.1 Meter toolbar

 Pause display of meter signals, when checked, all the meter signals refresh tasks are paused.

 Add a CAN signal from database.

 Add a LIN signal from database.

 Enable customization of the layout of meters.

 Select meter display style.

 Delete the selected meter signals.

 Delete all the signals in meter window.

### 1.12.2 Meter Layout Control

You can simply click customization button  to control each meter layout:




Fig 60 Meter Control customization

Then you can directly drag and drop each meter to your desired location:




Fig 61 Meter Control drag and drop

After the customization window is closed, you are leaving the customization mode.

Another way to quick customize the meter is to directly drag the caption area of each meter to align it:




Fig 62 Drag caption area to align it

### 1.12.3 Meter signal editor

CAN Signal Parameter	Value
Name	CarSpeed
Length	8
Byte Order	Intel
Value Type	Unsigned
Minimum	0
Maximum	511.5
Unit	mph
Factor	0.5
Offset	0
UI Size:	200
	200
Switch Type:	Circular
<input type="button" value="Delete"/> <input checked="" type="button" value="Apply"/> <input type="button" value="Cancel"/>	

Fig 63 Meter signal editor

**Name:** the name of the signal to be displayed.

**Length:** signal bit count.

**Byte Order:** can be Intel or Motorola.

**Value Type:** can be Unsigned, Signed, 32-bit float or 64-bit float.

**Minimum:** the minimum physical value of the signal, this setting also affects the graphical minimum range.

**Maximum:** the maximum physical value of the signal, this setting also affects the graphical maximum range.

**Unit:** the unit of signal physical value.

**Factor:** the enlarge factor of the physical value of signal.

**Offset:** the offset value of the physical value of the signal.

UI Size in width and height: user can adjust the size of the meter by modifying these parameters.

Switch Type: the following types are supported:








Fig 64 The type of meter display


## 1.13 LIN Trace

### 1.13.1 Trace toolbar

 Pause display button, when checked, the “Pause” button will switch to “Continue”  and incoming events will not be refreshed on the screen. The incoming events will be visible again when the “Continue” button is clicked.


 Clear the display of the current trace window.

 This checkbox sets trace window in chronological view mode. In this mode every incoming new message will be display as one trace line.

 This checkbox sets trace window in relative time mode.

 This checkbox ensures the trace list always scroll to the latest message.

 Expand all message nodes to view their signal values.

 Collapse all message nodes so signals are hidden.

Filter String:                      speed                       Filter trace list with specified

string, the filter string can be the following types:




Fig 65 Filter by identifier




Fig 66 Filter by signal name




Fig 67 Filter by message name




Fig 68 Filter by signal symbol value




Fig 69 Filter by signal numeric value



Clear filter value, the trace list will then display all the trace lines.



Message filter tool, which allows specific message identifiers to display in the trace, and meanwhile blocks other message identifiers. User can use this message filter to hide some irrelevant messages, or just monitor certain messages.



### 1.13.2 Trace message identifier filter




Fig 70 Trace message identifier filter

The trace message identifier filter works under either of the two conditions:

3. Block mode  Pass  Block

The message identifier in the list will be blocked, and other message will pass the filter. In the above picture, only 0x12 will be blocked, while other message identifiers will be displayed in the trace window.

4. Pass mode  Pass  Block

The message identifier in the list will be passed, and other message will be blocked. In the following picture, only 0x12 will be refreshed in the trace list:




Fig 71 Message identifier filter working in pass mode

To add or delete message identifiers in the list, just right-click on the empty area of the list, you will see the following popup menu items:






Fig 72 Add or delete message identifiers in the list




Add LIN frame identifiers from database or on the fly. These added message identifiers will be passed to the trace list. These menu items will be shown when the filter is in pass mode.




Add LIN frame identifiers from database or on the fly. These added message identifiers will be blocked and will not be displayed in the trace list. These menu items will be shown when the filter is in block mode.



This operation will remove the selected message identifier from the filter list.



This operation clears all the message identifier items from the filter list.



This checkbox controls whether the message identifier filter is enabled or not.

### 1.13.3 Trace list columns

**Absolute Time:** Absolute measurement time in seconds, this is the default time display format. The absolute time or message will be displayed in this column.

**Relative Time:** The relative time indicates the time in relation to the preceding message. In chronological mode this is the message received directly before the

current message, whereas in fixed position mode the relative time is displayed in relation to the previous message of the same type.

**Chn:** The channel number of the message.

**Identifier:** LIN message identifier.

**FPS:** Frames per second, this column displays the frame rate of specific identifier.

**Message Name:** The name of the message defined in the database.

**Checksum:** LIN frame checksum value read by tool.

**Dir:** Direction of the LIN message, can be Tx (transmit) or Rx (receive)

**DLC:** Data length code from LIN messages.

**Message Data Bytes:** Each data byte of the message.




Fig 73 Message data bytes with index starting from 0

### 1.13.4 Trace Signals Display

Trace signals can be expanded if a message is defined in the loaded LIN database:




Fig 74 Signals with updated values highlighted

### 1.13.5 Popups Menus

Most of trace popup menu items can be found in trace toolbar except “Copy” and

“Block selected message”:




Fig 75 Trace popup menu

To copy the trace lines, the user has to select certain trace lines and then click the “Copy” item. The selected text has the same layout as trace display:




Fig 76 Selected trace lines in text

## 1.14 LIN Transmit

















Fig 77 LIN Transmit


### 1.14.1 Transmit toolbar

-  Add a LIN message from database.
-  Add a raw LIN message directly into transmit list, which can be freely modified.
-  Copy selected LIN messages into clipboard, which can be pasted into current transmit list.
-  Paste the copied LIN message from clipboard into the current transmit list.
-  Delete the selected LIN messages from current list
-  Remove all the LIN messages from current list.
-  Add a new schedule table.
-  Delete the selected schedule table including its messages and signals.
-  Save the current transmit list to an external file. For the first time a save dialog box appears for the user to specify destination file. The following save operations will overwrite this file.
-  Export the current transmit list to an external file.

 Load transmit list from external file, this operation will overwrite all the existing transmit list.

 Select LIN node, this will popup a LIN database window for the user to choose LIN node. After a LIN node is selected, the message list and schedule tables are associated with this node for simulation.

 Deploy the schedule table into the hardware. The LIN hardware will automatically perform LIN message transmission.

 Undeploy all LIN messages. When this button is clicked, the scheduled LIN frames in the hardware are stopped.

### 1.14.2 LIN schedule table list




Fig 78 LIN schedule tables

The LIN schedule table list displays all the schedule tables of the current master node. If the current LIN node is not LIN master, this page is automatically hidden. Select one item in the list will display all the frame list on the message list.

### 1.14.3 Transmit list

The transmit list contains messages to be edited, each message has the following properties:

**Row:** The number of each transmit message in ascending order, this field is read-only and cannot be edited.

**Enable:** Activate or deactivate the current LIN frame.

**Message Name:** The name of the message, if this message is added from LIN database, then the message name is defined by LIN database and cannot be modified

by user; if this message is added manually, then the name of the message can be freely altered by user.

**Id:** Identifier of LIN message.

**Chn:** The channel number of LIN message.

**DLC:** Data length code of the LIN message, which can be within range 0~8.

**D0~D7:** LIN data frame data byte editors.

**Delay Time (ms):** LIN frame transmit delay time in milliseconds.

**Comment:** User can edit the comment of each LIN frame.

### 1.14.4 Signals list

Signals list displays editors for modifying signal properties of the selected LIN message defined in LIN database. The raw LIN messages do not have signals list editors.

Signal Name	Signal Gen.	Generator	Raw Value	Raw Step	Physical Value	Phys Step	Comment
Klemme_15		None	0	1	0	0.05	
Klemme_X		None	0	1	[0] aus	0.05	
KiSi		None	0	1	[0] aus	0.05	
SAD_Freigabe		None	0	1	[0] aus	0.05	
KL_Umluftbetrieb_aktiv		None	0	1	[0] inaktiv	0.05	
Schlechtwegausblendung		None	0	1	[0] aus	0.05	
Entnormierung_SAD		None	0	1	[0] aus	0.05	
ESP_v_Signal_8Bit		Sine	0	C	0	12.75	
Aussentemp_gef		None	0	C	-50	12.75	
KomfortAuf_MD1_Ausstellage		None	0	1	[0] aus	0.05	
KomfortAuf MD1 Schiebelaece		None	0	1	[0] aus	0.05	


Fig 79 Signals list of the selected LIN message



#### 1.14.4.1 Signal Name

The signal name defined in the LIN database.

#### 1.14.4.2 Signal Gen.

The signal value generator feature, which has three buttons for sending and configuring the value changing behavior of each LIN signal:

-  Start generating of the current signal. Once this button is clicked, the button changes to “Pause” button shown below.


-  Pause button, once this button is clicked, the current LIN signal generator pauses, the button then changes back to “Send” button shown above.
-  Stop button, a click on this button stop the operation of the current LIN signal generator.

#### 1.14.4.3 Generator

This combobox specifies the generator type of the current LIN signal, which is described in “CAN Transmit Window”.

#### 1.14.4.4 Raw Value

Raw value editor of the current selected signal. To modify a signal’s raw value without touching its physical value, use this editor.


 Increment and decrement button of the raw value. Clicking on the corresponding button increments or decrements the raw value by the step defined on the “Raw Step” field.

#### 1.14.4.5 Raw Step

The increment or decrement step of the “Raw Value” field.

#### 1.14.4.6 Physical Value

Physical value editor of the current selected signal. To modify a signal’s physical value without touching its raw value, use this editor.

 Increment and decrement button of the physical value. Clicking on the corresponding button increments or decrements the physical value by the step defined on the “Phys Step” field.

#### 1.14.4.7 Phys Step



The increment or decrement step of the “Physical Value” field.

#### 1.14.4.8 Comment

User comment on the specified signal.

### 1.15 LIN Database

LIN database viewer can be used to load/unload LIN database, select LIN messages or LIN signals in the TSMaster application.









Fig 80 LIN Database

#### 1.15.1 LIN database toolbar

-  Add a LIN database from external \*.ldf file
-  Edit the current selected database (\*.ldf file) using default editor on this computer
-  Delete the current selected database from the database list
-  Delete all the database links from the database list
-  Increase a channel resource for database file mapping

- Decrease a channel resource for database file mapping
- ↓ Expand all nodes in the database treeview
- ↑ Collapse all nodes in the database treeview

Filter by: database element filter, can be the following for user to select in database element selector mode:

- Show All: all the database elements will be displayed in the treeview
- LIN Signal: Only LIN signals are displayed
- LIN Message: Only LIN messages are displayed
- LIN Node: Only LIN nodes are displayed
- Environment Variable: Only environment variables are displayed

### 1.15.2 LIN database channel assignment

LIN database channel assignment enables the user to associate the selected database with specific LIN channels. A LIN database can support only one LIN channel, or multiple channels.




Fig 81 Channel assignment

When there are multiple database files loaded, the user may right-click on the specific LIN channel, which pops up a list of available LIN databases. The user can associate / deassociate the database with the currently selected LIN channel by clicking on the database item in the popup menu.

### 1.15.3 LIN element treeview




Fig 82 LIN element treeview

The LIN element treeview displays all the loaded LIN database information including LIN network, LIN signals, LIN messages, LIN nodes, LIN schedule tables and Environment variables.

## 1.16 TS Channel Mapping

TS channel mapping window is a tool for the management of hardware and logical channel mappings.




Fig 83 TS Channel Mapping

### 1.16.1 TS Channel Mapping toolbar

- ➡ Expand all the tree nodes of hardware list.
- ⬆ Collapse all the tree nodes of hardware list.
- 🔄 Refresh hardware channel and logical channel lists.

### 1.16.2 Hardware channel and application list

The list has two main groups: hardware channels and applications:




Fig 84 Hardware channels and applications

The hardware list displays each hardware devices and available channels inside the device.

The application list displays all the applications that requires mapping.

### 1.16.3 Map a hardware channel with a logical application channel

There are several ways for a user to map.

- Right click on the hardware channel




Fig 85 Right click on the hardware channel

- Right click on the application logical channel




Fig 86 Right click on the logical channel

### 1.16.4 Add or delete an application

To add a new application, right-click on the “Application” group and select “Add application...” menu item.




Fig 87 Add a new application

To delete an existing application, right-click on the specified application, and select “Delete application...” menu item.




Fig 88 Delete application

### 1.16.5 Set channel count of a bus type

To set the channel count of a bus type such as LIN bus, right-click on the “LIN channels” group and select “Set channel count” menu item:




Fig 89 Set application channel count

## 1.17 Software Configuration

The software configuration controls each application form's status:




Fig 90 Software configuration

The list contains all the opened application windows. With the help of its pop-up menu, the user can delete the selected window, rename the selected window and also create new window to perform specific tasks.

## 1.18 TS Log Converter

### 1.18.1 Log file types

TS log file converter can be started in “Analysis – Log Converter”, which converts log files from one format to another format. The following formats are supported:

Table 2 TS Log Converter capabilities

Source format	Destination format	Support	Comments
asc	blf	●	
asc	mat	●	dbc required
blf	asc	●	
blf	mat	●	dbc required
mat	asc	○	
mat	blf	○	

### 1.18.2 Log converter interface




Fig 91 Log converter interface

Source File: the source log file to be converted, acceptable file types can be “\*.asc” and “\*.blf”.

Destination File: the destination log file for the conversion result, acceptable file types can be “\*.asc”, “\*.blf” and “\*.mat”.

CAN Databases: the additional CAN database file list for user to load “\*.dbc” file.

Note: only “\*.mat” output file requires this section.

Help: opens this help file.

Convert: starts conversion based on the specified source and destination file.



Stop: stop conversion.

### 1.18.3 Mat File Example

Load sample dbc “Powertrain.dbc” and “Comfort.dbc” into TSMaster. Stimulate the “EngSpeed” signal with signal generator in the transmit window.




Fig 92 Load dbc and stimulate EngSpeed signal

Start logging of blf file and after some while stop logging.

After blf file is created, load the blf file in TS log converter and associate dbc files:




Fig 93 Specify log files and database files

After the log file has been converted, drag the mat file into MATLAB, find the signal “EngSpeed” in the workspace, and plot it by clicking “plot” in the popup menu, you will see the signal trace.




Fig 94 Find signal "EngSpeed" and plot it




Fig 95 EngSpeed signal has been plotted

## 1.19 CAN Remaining Bus Simulation

CAN Remaining Bus Simulation (CAN RBS) is a software module performing CAN Bus simulation that sending background messages of network nodes defined in the CAN databases.

Please refer to the following examples to use CAN RBS simulation on UI, or with scripts:

*“CAN Remaining Bus Simulation UI.T7z”*

*“CAN Remaining Bus Simulation Scripting.T7z”*




Fig 96 CAN Remaining Bus Simulation Examples




Fig 97 CAN Remaining Bus Simulation

1.19.1 CAN RBS toolbar

➤ Start simulation, the activated message in the list will be scheduled in the transmission engine.

■ Stop simulation, all the message transmissions are halted.

⬇ Expand all nodes to view their transmission messages.

⬆ Collapse all nodes so messages are hidden.

☐ Select all messages in the list.

☐ Deselect all messages in the list.

### 1.19.2 CAN RBS message list

The CAN RBS message list displays all the information and properties of each node's transmit message. User can modify message properties while the simulation is running.

The screenshot shows two windows from the TSMaster software. The top window, titled 'CAN Trace', displays a table of messages:

Absolute Time	Chn	Identifier	FPS	Message Name	Type	Dir	DLC	Message Data Bytes
238.406632	1	18FEA400x	1		Data	Rx	8	20 22 20 22 00 7D 20
238.394844	2	18FEA400x	1		Data	Tx	8	20 22 20 22 00 7D 20
238.407361	1	18FEEE00x	1		Data	Rx	8	28 28 20 22 20 22 28
238.395581	2	18FEEE00x	1		Data	Tx	8	28 28 20 22 20 22 28
238.412923	1	18FEF500x	1		Data	Rx	8	00 20 22 20 22 28 20
238.401135	2	18FEF500x	1		Data	Tx	8	00 20 22 20 22 28 20
239.356969	1	41D	100	NM_Gateway	Data	Tx	4	12 00 00 00
239.345181	2	41D	100		Data	Rx	4	12 00 00 00

The bottom window, titled 'CAN Remaining Bus Simulation', shows a tree view of the simulation components and a table of messages:

Channel	Network	ECU	Messages	Interval (ms)	Id	Type	DLC	Data Bytes
Channel 1				-	-	-	-	
	Comfort			-	-	-	-	
		Gateway		-	-	-	-	
			DiagResponse_Motor	0	0x601	CAN Standard	8	00 00 00 00 00 00 00 00
			NM_Gateway	10	0x41D	CAN Standard	4	12 00 00 00
			Gateway_2	100	0x111	CAN Standard	8	00 00 00 00 00 00 00 00
			Gateway_1	20	0x110	CAN Standard	3	00 00 00
		DOOR_r1		-	-	-	-	
			NM_DOORright	0	0x41C	CAN Standard	4	00 00 00 00
			DOOR_r	100	0x1F1	CAN Standard	1	00

Fig 98 CAN RBS list

The fields that support dynamic assignment are:

- Message interval (ms)
- Message identifier

- Message DLC
- Message data bytes

### 1.19.3 Modify Signal In CAN RBS

You can expand the message to directly modify its signal value, which will take effect immediately:




Fig 99 Modify signal value in RBS in UI

You can also modify signals in scripts, please refer to example: *“CAN Remaining Bus Simulation Scripting.T7z”*

## 1.20 C Script Editor

C Script editor is a C implementation of TS Mini Program. TSMaster C script enables the user to utilize maximum abilities of TSMaster main application.








Fig 100 C Code Editor user interface

### 1.20.1 C Script Editor toolbar

-  Undo and Redo the modification you made in the script.
-  Copy, Paste and Cut the selected text in the script editor.
-  Expand or collapse the left symbol tree or function tree.
-  Editor color configuration, which brings up a syntax color editor for you to choose styles:











Fig 101 Color editor

-  Import an external mpc file into this code editor.
-  Save the current mpc file, the system will automatically save this file when application configuration is saved.
-  Export the current mpc file to another location. Note: the script location you are editing won't be changed. This is just an export operation.
-  Search a text sequence.
-  Search next, this feature has a shortcut "F3", which is really useful when you want to jump to the location of the same text sequence currently selected.
-  Replace a text sequence.
-  Opens the directory containing the compiled script, after successful compilation, you will find a ".mp" file inside this directory, drag this file into TSMaster will cause TSMaster treats this file as a mini program library:







Fig 102 Compiled mini program location

-  Compile the current mini program. Error information will popup if your syntax is incorrect.
-  Run the current mini program, if the source file is changed, the mini program

is firstly compiled then executed by the TSMaster.

-  Stop the execution of the current mini program.

## 1.20.2 Symbol Tree


The symbol tree items are described as below:

Source code editor		Properties
Program	[1]	[7 items]
Code Generation	[2]	View Source
TSMaster Header	[3]	View TSMaster Header
Database Header	[4]	View Database Header
Test Header	[5]	Test Header
Global Definition	[6]	Add definitions
Step Function	[7]	Main step function
Documentation	[8]	Edit documentation
Variables	[9]	[1 items]
NewVariable1	[10]	Integer
Timers	[11]	[1 items]
Timer1000ms	[12]	1000 ms
On CAN Rx	[13]	[2 items]
NewOn_CAN_Rx1	[14]	0x123
NewOn_CAN_FD_Rx1	[15]	0x123 (FD)
On CAN Tx	[16]	[2 items]
NewOn_CAN_Tx1	[17]	0x123
NewOn_CAN_FD_Tx1	[18]	0x123 (FD)
On CAN PreTX	[19]	[2 items]
NewOn_CAN_PreTx1	[20]	0x123
NewOn_CAN_FD_PreTx:	[21]	0x123 (FD)
On LIN Rx	[22]	[1 items]
NewOn_LIN_Rx1	[23]	0x12
On LIN Tx	[24]	[1 items]
NewOn_LIN_Tx1	[25]	0x12
On LIN PreTX	[26]	[1 items]
NewOn_LIN_PreTx1	[27]	0x12
On Var Change	[28]	[1 items]
NewOn_Var_Change1	[29]	[NewVariable1]
On Timer	[30]	[1 items]
ReadSignalValue	[31]	[Timer1000ms]
On Start	[32]	[1 items]
Start_RBS	[33]	
On Stop	[34]	[1 items]
Stop_RBS	[35]	
On Shortcut	[36]	[1 items]
NewOn_Shortcut1	[37]	Ctrl+R
Custom Functions	[38]	[1 items]
NewCustom_Function1	[39]	

Fig 103 Symbol tree items




### 1.20.2.1 Program group



The program group contains mini program related headers, sources and documentation.

### 1.20.2.2 Code Generation




This section contains all generated source code of this mini program.

This source code is read-only, to solve problems of your code during compile, you should first goto error line to identify problems, and then navigate to the associated code section to correct problems.

```
// Generated source code (Read-Only)
1  #define TSMP_IMPL
2  #include "TSMaster.h"
3  #include "MPLibrary.h"
4  #include "Database.h"
5  #include "Test.h"
6
7  // Variables defintions
8  TMPVarInt NewVariable1;
9
10 // Timers defintions
11 TMPTimerMS Timer1000ms;
12
13 // Function Prorotypes
14 s32 NewCustom_Function1(s32 A1, s32 A2);
15
16 // Global definitions
17
18 s32 vGear = 0;
19
20
21 // Main step function being executed every 5 ms
22 void step(void) { // interval = 5 ms
23
24 }
```

Fig 104 Code generation page

### 1.20.2.3 TSMaster Header




This section contains all interface definitions of TSMaster mini program, to find out record, typedef of TSMaster mini program symbols such as "TCAN", "PCAN", Please refer to this section.

```
// TSMaster header (Read-Only)
100 0, 1, 2, 3, 4, 5, 6, 7,
101 8, 12, 16, 20, 24, 32, 48, 64
102 };
103
104 // CAN frame type =====
105 typedef struct {
106     u8 FIdxChn;
107     u8 FProperties;
108     u8 FDLC;
109     u8 FReserved;
110     s32 FIdentifier;
111     s64 FTimeUs;
112     u8 FData[8];
113     // is_tx -----
114     PROPERTY(bool, is_tx);
115     GET(is_tx)
116     {
117         return (FProperties & MASK_CANProp_DIR_TX) != 0;
118     }
119     SET(is_tx)
120     {
121         if (value) {
122             FProperties = FProperties | MASK_CANProp_DIR_TX;
123         } else {
124             FProperties = FProperties & (~MASK_CANProp_DIR_TX);
125         }
126     }

```

Fig 105 TSMaster header

#### 1.20.2.4 Database Header



This sections contains all message and signal definitions from any loaded dbc/ldf databases.

To manipulate a CAN signal for example, you should:

- [1] Load specific dbc file into TSMaster
- [2] Switch to this section, you will see all the extracted database symbols
- [3] Navigate to "Functions" tab on the right, you will see messages in this tree
- [4] Right-click on one of the messages such as "Configure\_1", and select "Insert into script"

This will insert the definition of "Configure" message on Channel 1 into the current script, such as:

```
TConfigure_1 Configure_1;
Configure_1.init();
```

[5] the last inserted line "Configure\_1.init();" is initialization method of message "Configure\_1"

you should cut this line to place before any code which access "Configure\_1"

[6] then you can get or set its signals freely:

To get signal value "FL\_Speed": result = Wheel\_Speed\_1.FL\_Speed;

To set signal value "FL\_Speed": Wheel\_Speed\_1.FL\_Speed = 12.3;

[7] To send this message out, just use the following code:


```
com.transmit_can_async(&Wheel_Speed_1.FCAN);
```

where "FCAN" is its internal CAN message object, which contains all raw data bytes of this messageNote: Compile will fail if databases are loaded with same message names in the same channel.

```
// Database header (Read-Only)
1  #ifndef __DATABASE_H
2  #define __DATABASE_H
3  #include "TSMaster.h"
4
5  // CAN Databases
6  struct _New_Message_18_1;
7  typedef struct _New_Message_18_1 TNew_Message_18_1;
8  struct _New_Message_18_1{
9      TCAN FCAN;
10     PROPERTY(double, New_Signal_51);
11     void init() {}
12     void set_data(const PCAN ACAN) { FCAN = *ACAN; }
13 };
14
15 struct _New_Message_17_1;
16 typedef struct _New_Message_17_1 TNew_Message_17_1;
17 struct _New_Message_17_1{
18     TCAN FCAN;
19     PROPERTY(double, New_Signal_50);
20     void init() {}
21     void set_data(const PCAN ACAN) { FCAN = *ACAN; }
22 };
```

Fig 106 Database Header

### 1.20.2.5 Test Header




This section contains all parameter definitions of the test system that uses this mini program as test case.

You can locate any parameter you previously defined in test system.

After parameters are defined, the "Test Header" section will reflect all the

parameter definitions using C code.



Global Parameters (All DUTs share the same parameters)				
Index	Type	Name	Value	Description
1	s32	fps_1k_min	990	min frame rate in 1000 fps
2	s32	fps_1k_max	1010	max frame rate in 1000 fps
3	s32	std_data_id	123	identifier of standard data frame
4	s32	ext_data_id	234567	identifier of extended data frame
5	s32	std_remote_id	178	identifier of standard remote frame
6	s32	ext_remote_id	7598125	identifier of extended remote frame
7	s32	std_fd_id	456	identifier of standard fd frame
8	s32	ext_fd_id	196183478	identifier of extended fd frame
9	s32	fps_2k_min	1990	min frame rate in 2000 fps
10	s32	fps_2k_max	2010	max frame rate in 2000 fps
11	s32	fps_3k_min	2990	min frame rate in 3000 fps
12	s32	fps_3k_max	3010	max frame rate in 3000 fps
13	s32	fps_4k_min	3990	min frame rate in 4000 fps
14	s32	fps_4k_max	4010	max frame rate in 4000 fps

DUT Parameters (Different in each DUT)				
Index	Type	Name	Value	Description

Fig 107 Parameters defined in test system

```
// Test header (Read-Only)
1  #ifndef __TEST_H
2  #define __TEST_H
3  #include "TSMaster.h"
4
5  typedef struct {
6      s32 fps_1k_min; // min frame rate in 1000 fps
7      s32 fps_1k_max; // max frame rate in 1000 fps
8      s32 std_data_id; // identifier of standard data frame
9      s32 ext_data_id; // identifier of extended data frame
10     s32 std_remote_id; // identifier of standard remote frame
11     s32 ext_remote_id; // identifier of extended remote frame
12     s32 std_fd_id; // identifier of standard fd frame
13     s32 ext_fd_id; // identifier of extended fd frame
14     s32 fps_2k_min; // min frame rate in 2000 fps
15     s32 fps_2k_max; // max frame rate in 2000 fps
16     s32 fps_3k_min; // min frame rate in 3000 fps
17     s32 fps_3k_max; // max frame rate in 3000 fps
18     s32 fps_4k_min; // min frame rate in 4000 fps
19     s32 fps_4k_max; // max frame rate in 4000 fps
20 } TGlobalParameters, *PGlobalParameters;
// Test header end
```

Fig 108 Test Header

### 1.20.2.6 Global definition

#### Global Definition

This section contains all your global definitions, which will be placed before all event functions such as "#include <xxx>", or "s32 vVar1;", etc.

```

// Global definitions
1
2  s32 vGear = 0;
3

```

Fig 109 Global definitions

When you define global variables in the source, they will be generated on top of the source in “Code Generation”:


```

// Generated source code (Read-Only)
1 #define TSMP_IMPL
2 #include "TSMaster.h"
3 #include "MPLibrary.h"
4 #include "Database.h"
5 #include "Test.h"
6
7 // Variables definitions
8 TMPVarInt NewVariable1;
9
10 // Timers definitions
11 TMPTimerMS Timer1000ms;
12
13 // Function Prototypes
14 s32 NewCustom_Function1(s32 A1, s32 A2);
15
16 // Global definitions
17 s32 vGear = 0;
18
19
20

```

Fig 110 Globally defined variables in "Code Generation"

### 1.20.2.7 Step Function



The function in this section will be automatically executed periodically, such as step function of ECU tasks, or any periodic task.

Double click on this section will popup property editor, in which you can specify period in milliseconds.

The dialog box for step function configuration contains the following fields and buttons:

- Name:** A text input field containing the value "step".
- Interval (ms):** A dropdown menu with the value "5" selected.
- Buttons:** Two buttons at the bottom: "Apply" (with a green checkmark icon) and "Cancel" (with a red X icon).

Fig 111 Step function configuration

In the example of TSMaster – CarSim cosimulation example, you can see the

algorithm of ABS function is invoked in the step function every 5ms.

You can first prepare function inputs before “abs\_SLX\_CS9\_step” is called, and retrieve function outputs after “abs\_SLX\_CS9\_step” is called. You can then plot the important signals in Graphics, panels and so on. You can even plot internal, or temp. variables, too.


```

void step(void) { // interval = 1 ms
1  if (app.check_terminate()) return;
2
3  // prepare inputs
4  abs_SLX_CS9_U.vFL = *vFL;
5  abs_SLX_CS9_U.vFR = *vFR;
6  abs_SLX_CS9_U.vRL = *vRL;
7  abs_SLX_CS9_U.vRR = *vRR;
8  abs_SLX_CS9_U.vVeh = *vVehLong;
9  abs_SLX_CS9_U.pMC = *pMCPressure;
10
11 // call step function
12 abs_SLX_CS9_step();
13
14 // get outputs
15 *pFL = abs_SLX_CS9_Y.pFL;
16 *pFR = abs_SLX_CS9_Y.pFR;
17 *pRL = abs_SLX_CS9_Y.pRL;
18 *pRR = abs_SLX_CS9_Y.pRR;
19
20 // monitor signals
21 vWFL.set(*vFL);
22 pWFL.set(*pFL);
23 vVeh.set(*vVehLong);
24 pMC.set(*pMCPressure);
25
}

```

Fig 112 Step function of ABS SIL test

### 1.20.2.8 Documentation



This section contains documentation texts of this mini program.

You can write comments or descriptions of this mini program here, steps to create mini program:

[1] modify your program name in "Properties" - "Program Settings" - "Program Name"

[2] add events or write your logic in "Step Function"

[3] press F9 to run your code





Fig 113 Documentation of mini program

### 1.20.2.9 Variables Group



Variables group contains globally defined variables in the current mini program.


If you define variable here, such as "v1" of double type, you should use it with the following method:

[1] read this variable: `double d = v1.get();`

[2] write this variable: `v1.set(12.34);`

[3] watch this variable in realtime: just run your mini program, you will see this variable value in "Variables" page.

### 1.20.2.10 Variable






Fig 114 Variable in mini program

When you double click a variable in the group, you will see a popup appears, in which you can modify the variable name, and type.

Note: each variable you defined in the “Variables Group” will become an internal system variable in TSMaster when this script is being executed, that is, you can monitor this variable in real-time in Graphics, Panels or even in your other mini programs. Please refer to TSMaster example “System Variables in Mini Program” for details:




Fig 115 Variables will become System variables

### 1.20.2.11 Timers Group






Timer group contains every timer you defined. To use timer, you should for example:

- [1] define a timer in this group such as "tim1"
- [2] set the period(ms) of this timer such as 10ms
- [3] define a on timer callback "OnTim1" in "On Timer" group and associate the callback with this timer
- [4] start the timer using "tim1.start();"
- [5] now in callback "OnTim1", your code of this function will be executed every 10ms

### 1.20.2.12 Timer



When you double click on a timer, you will see a popup showing the properties of the current selected timer. You can modify the name, and interval in milliseconds.





Fig 116 Timer definition

### 1.20.2.13 On CAN Receive Event Group



CAN receive event group contains every CAN / CAN FD reception callback you defined. To use a reception callback, you should for example:

- [1] define a callback named "OnRx123" with an identifier "0x123", this means message with id = 0x123 will fire this event


If you want to trigger ANY Rx frame, just leave the identifier text box blank

[2] you will get parameter "ACAN" in this event to operate with

Such as: ACAN->FData[0] to access the first data byte of this received message

Please see "TSMaster Header" section on the left tree to find out data type and elements of "TCAN"

### 1.20.2.14 On CAN Receive Event

 NewOn\_CAN\_Rx1

When you double click on the event, you will see a popup showing the properties of this event. You can modify the name, identifier of this event. Switch on or off "CAN FD Message" will change the event type to be "CAN FD" event or "Classical CAN" event.




Fig 117 On CAN Rx Event

When a database is assigned, you can pick any CAN message from the database by clicking "..." button on the right side of the "Id" input box.




Fig 118 CAN message selector for On Rx event

After the message is selected, you can see the information is automatically inserted into the input box:




Fig 119 CAN message information automatically inserted

After you click "Apply" or press enter key, you can see the information is recognized by the script editor:





Fig 120 On message information recognized by the editor

### 1.20.2.15 On CAN FD Receive Event

 NewOn\_CAN\_FD\_Rx1

When you double click on the event, you will see a popup showing the properties of this event. You can modify the name, identifier of this event. Switch on or off “CAN FD Message” will change the event type to be “CAN FD” event or “Classical CAN” event.





Fig 121 On CAN FD Rx Event

#### 1.20.2.16 On CAN Transmit Event Group

 On CAN Tx

CAN transmit event group contains every CAN / CAN FD transmit callback you defined.

Note: only transmitted frame (ACKed by other node) fires transmit callback. TOSUN, Vector and IntrepidCS hardware have ability to get correct timestamp of transmitted frame

To use a transmit callback, you should for example:

[1] define a callback named "OnRx123" with an identifier "0x123", this means message with id = 0x123 will fire this event

If you want to trigger ANY Tx frame, just leave the identifier text box blank

[2] you will get parameter "ACAN" in this event to operate with

Such as: ACAN->FData[0] to access the first data byte of this received message

Please see "TSMaster Header" section on the left tree to find out data type and elements of "TCAN"

#### 1.20.2.17 On CAN Transmit Event

NewOn\_CAN\_Tx1

When you double click on the event, you may see the properties popup showing, which is similar to “On CAN Receive Event”:




Fig 122 On CAN Transmit event

### 1.20.2.18 On CAN FD Transmit Event

NewOn\_CAN\_FD\_Tx1

When you double click on the event, you may see the properties popup showing, which is similar to “On CAN Receive Event”:




Fig 123 On CAN FD Transmit event

### 1.20.2.19 On CAN Pre-Transmit Event Group

On CAN PreTX

CAN pre-Tx event group contains every CAN pre-Tx callback you defined.

Note: This feature is introduced by TOSUN for users to interact with >>> EACH <<< frame being transmitted

This is really useful when you want to modify frame content, or frame type before this frame is sent

Use this feature with care

To use a pre-Tx callback, you should for example:

[1] define a callback named "OnPreTx123" with an identifier "0x123", this means message with id = 0x123 will fire this event

If you want to trigger ANY pre-Tx frame, just leave the identifier text box blank

[2] you will get parameter "ACAN" in this event to operate with

Such as: `ACAN->FData[0]` to access the first data byte of this received message

If you want to force the first byte to 0, write this code: `"ACAN->FData[0] = 0;"`

Please see "TSMaster Header" section on the left tree to find out data type and elements of "TCAN"

Please also refer to the example "Checksum And Rolling Counter" to maximize the ability of "Pre-Tx" event:




Fig 124 Checksum and Rolling Counter example based on Pre-Tx event

### 1.20.2.20 On CAN Pre-Transmit Event

When you double click on the event, you may see the properties popup showing, which is similar to “On CAN Receive Event”:





Fig 125 On CAN Pre-Transmit event

### 1.20.2.21 On CAN FD Pre-Transmit Event



When you double click on the event, you may see the properties popup showing, which is similar to “On CAN Receive Event”:





Fig 126 On CAN FD Pre-Transmit event

### 1.20.2.22 On LIN Receive Event Group



LIN receive event group contains every LIN reception callback you defined. To use a reception callback, you should for example:

[1] define a callback named "OnRx12" with an identifier "0x12", this means message with id = 0x12 will fire this event


If you want to trigger ANY Rx frame, just leave the identifier text box blank

[2] you will get parameter "ALIN" in this event to operate with

Such as: ALIN->FData[0] to access the first data byte of this received message

Please see "TSMaster Header" section on the left tree to find out data type and elements of "TLIN"

### 1.20.2.23 On LIN Receive Event

 NewOn\_LIN\_Rx1

When you double click on the event, you may see the properties popup showing, which is similar to "On CAN Receive Event":





Fig 127 On LIN Receive Event

### 1.20.2.24 On LIN Transmit Event Group

 On LIN Tx

LIN transmit event group contains every LIN transmit callback you defined.

Note: only transmitted frame fires transmit callback

TOSUN, Vector and IntrepidCS hardware have ability to get correct timestamp of transmitted frame

To use a transmit callback, you should for example:

[1] define a callback named "OnRx12" with an identifier "0x12", this means message with id = 0x12 will fire this event

If you want to trigger ANY Tx frame, just leave the identifier text box blank

[2] you will get parameter "ALIN" in this event to operate with


Such as: ALIN->FData[0] to access the first data byte of this received message

Please see "TSMaster Header" section on the left tree to find out data type



and elements of "TLIN".

### 1.20.2.25 On LIN Transmit Event

 NewOn\_LIN\_Tx1

When you double click on the event, you may see the properties popup showing, which is similar to "On CAN Receive Event":





Fig 128 On LIN Receive Event

### 1.20.2.26 On LIN Pre-Transmit Event Group

 On LIN PreTX

LIN pre-Tx event group contains every LIN pre-Tx callback you defined.

Note: This feature is introduced by TOSUN for users to interact with >>> EACH <<< frame being transmitted

This is really useful when you want to modify frame content, or frame type before this frame is sent

Use this feature with care

To use pre-Tx callback, you should for example:

[1] define a callback named "OnPreTx12" with an identifier "0x12", this means message with id = 0x12 will fire this event

If you want to trigger ANY pre-Tx frame, just leave the identifier text box blank


[2] you will get parameter "ALIN" in this event to operate with

Such as: ALIN->FData[0] to access the first data byte of this received message

If you want to force the first byte to 0, write this code: "ALIN->FData[0] = 0;"

Please see "TSMaster Header" section on the left tree to find out data type and elements of "TLIN"

### 1.20.2.27 On LIN Pre-Transmit Event

 NewOn\_LIN\_PreTx1

When you double click on the event, you may see the properties popup showing, which is similar to "On CAN Receive Event":





Fig 129 On LIN Pre-Transmit Event

### 1.20.2.28 On Var Change Event Group

 On Var Change

On Var Change group contains every global variable event you defined.


For example a variable named "v1" is changed using "v1.set()" method,

it will immediately trigger its associated on change event

To use on var change callback, you should for example:

- [1] define a variable named "v1" in "Variables" section on the left tree
- [2] define a "on var change" event in this section
- [3] associate its "Variable" property with "v1" in the drop down list
- [4] write your code in this event to deal with event of "v1" change

### 1.20.2.29 On Var Change Event

 NewOn\_Var\_Change1

When you double click on the event handler of variable change, you can see a popup showing the properties of this event, you can assign the variable when this event.





Fig 130 On Var Change Event


### 1.20.2.30 On Timer Event Group



On Timer group contains every timer event you defined. To use timer event, you should for example:

- [1] define a timer in group "Timers" such as "tim1"
- [2] set the period(ms) of this timer such as 10ms
- [3] define a on timer callback "OnTim1" in this group and associate the callback with this timer
- [4] start the timer using "tim1.start();"
- [5] now in callback "OnTim1", your code of this function will be executed every 10ms

### 1.20.2.31 On Timer Event



When you double click on a timer event, you can see a popup dialog showing the properties of this event. You can assign a timer to this event. So when the timer overflows, this event will be triggered.





Fig 131 On Timer Event

### 1.20.2.32 On Start Event Group




On Starts group contains every on start event you defined.

If you define more than one on start event, each event will be executed one by one when this script starts.

Note: No timer, receive or transmit events will be triggered in on start callback.

If you want to perform automated test with event support, move your test logic into step function.

### 1.20.2.33 On Start Event



When you double click on the event, you can see a popup dialog showing the properties of this event. You can modify the name of this event.




Fig 132 On Start Event

### 1.20.2.34 On Stop Event Group

### ■ On Stop

On Stops group contains every on stop event you defined.

If you define more than one on stop event, each event will be executed one by one when this script stops.

Note: No timer, receive or transmit events will be triggered in on stop callback.

#### 1.20.2.35 On Stop Event

### ■ Stop\_RBS

When you double click on the event, you can see a popup dialog showing the properties of this event. You can modify the name of this event.




Fig 133 On Stop Event

#### 1.20.2.36 On Shortcut Event Group

### ■ On Shortcut

On shortcuts group contains every shortcut associated event you defined.


To use on shortcut event, you should for example:

[1] define an on shortcut event named "OnKeyA" if you want to use keyboard A key to trigger

[2] In shortcut field, just press "A" key of your keyboard, so key A is associated with this event

[3] Write your code in this event content, so the code will be executed when this mini program starts and key A is pressed

### 1.20.2.37 On Shortcut Event

 NewOn\_Shortcut1

When you double click on the event, you can see a popup dialog showing the properties of this event. You can modify the name and associated shortcut of this event.





Fig 134 On Shortcut Event

Please refer to TSMaster example "Shortcuts.T7z" for detailed usage of shortcut events.

### 1.20.2.38 Custom Functions Group

 Custom Functions


Custom Functions group contains every function you defined.

To use custom functions, you should for example:

- [1] define a custom function in this group and name it "func1"
- [2] specify its parameters such as "const s32 A, const s32 B" if you want two parameters
- [3] write algorithm in this function such as "return A + B;"
- [4] in other place of this mini program, just call "r = func1(3, 5);" which will get result of 3 + 5 into variable r

Note: you can publish your custom function as mini program library to be invoked by other mini programs.

### 1.20.2.39 Custom Function

 NewCustom\_Function1

When you double click on the function, you can edit the name, and the parameters of this function.




Fig 135 Custom Function

Please refer to TSMaster example “Checksum And Rolling Counter.T7z” for detailed usage of custom function, in this example, a CRC-8 checksum algorithm is implemented in custom function.

## 1.21 Application Window Host

TS application window host enables external application to be hosted in TSMaster window. External application can be any type of program with main form for user interaction. It is very useful for user to manage multiple applications just within TSMaster user interface.








Fig 136 Application window host

-  Start external application in current form
-  Stop external application
-  Restart external application

 Settings ▾ Application configuration, which contains the following items:




Fig 137 Application settings

App Path: Specify full path of external application.

Delay Time (ms): Delay a certain time (ms) before the external application is hosted into current form.

Usage example steps for Carla integration:

- [1] Find Carla application full path, fill it into “App Path”
- [2] Set a certain delay time before this application is hosted, if application takes longer to start, set this value larger. In this example, the delay time is 5s






Fig 138 Carla Integration

- [3] Click start button  to run external application: Carla
- [4] You will see Carla application is hosted into this form
- [5] Click stop button  to terminate Carla application.
- [6] You can set “Auto-start” of this window so that Carla is automatically created when application is connected, and automatically destroyed when application is disconnected.






Fig 139 Auto start and stop Carla




Fig 140 Carla Integration Result

## 1.22 Panel

TSMaster panel allows users to create their own application interface to send messages, receive messages, signals and doing various operations based on TSMaster's sophisticated control architecture.

Please refer to TSMaster example "Panel Basics.T7z" to understand the abilities of TSMaster panel component.







Fig 141 TSMaster Panel Interface

### 1.22.1 Panel Toolbar



Edit mode selector, this selector controls the visibility of TSMaster internal panel editor. It has the following three states:


- 1)  Pressed state: means the panel is now in editor mode, you can modify the controls on panel freely.
- 2)  Unpressed state: means the panel is now in test mode, this mode shows how the panel will look like when application is started, you can view the panel control layout and make adjustment to its internal controls by click on this button again to activate edit mode.
- 3)  Disabled mode: means the TSMaster application is connected, the panel is now in running mode, no editor features available. If you want to edit the panel again, please first disconnect application.



Basic Copy, Paste, Cut and Delete function of panel controls, Note: you must first select one or multiple panel controls before performing these operations.



Bring to front, and Send to back function of panel controls.



Alignment adjustment of panel controls, which has the following sub

items for multiple selected items:





Fig 142 Alignment of panel controls


- Align Left: move all selected controls to left align
- Align Right: move all selected controls to right align
- Align Top: move all selected controls to top align
- Align Bottom: move all selected controls to bottom align
- Center Horizontally: move all selected controls to the same Y coordinates
- Center Vertically: move all selected controls to the same X coordinates
- Distribute Horizontally: move all selected controls so each has the same X gap with its nearest sibling
- Distribute Vertically: move all selected controls so each has the same Y gap with its nearest sibling

 Create a new panel, this will delete all the controls on the current panel

 Import a panel from external panel files, this will delete all the controls on

the current panel

 Export the current panel to external files

 **Settings** ▾ Panel settings, which has the following sub menus:




Fig 143 Panel settings sub menu

### 1.22.1.1 Panel Layout Settings




Fig 144 Panel layout settings

**Normal:** all panel controls will be displayed as is:




Fig 145 Normal panel layout settings

**Stretch:** all panel controls will be stretched to fill the display area:




Fig 146 Stretch panel layout settings

**Fit:** all panel controls will be adjusted to fit the display area, while keeping their x and y ratio fixed:




Fig 147 Fit panel layout settings

### 1.22.1.2 Panel Design Time Settings

Panel design time settings supports displaying panel variable link on bottom of each control:




Fig 148 Panel design time settings

If this option is switched on, you will see a complete variable database address text displayed on bottom:



Fig 149 Panel variable address display

### 1.22.2 Panel Controls

Please see the following picture demonstrating each TSMaster panel control:




Fig 150 TSMaster panel control overview

#### 1.22.2.1 Panel Common Properties

This section describes all common properties of panel controls:

Align	<b>None</b>
Enabled	<b>True</b>
Height	<b>43</b>
⊕ Margins	<b>(TBounds)</b>
Opacity	<b>1</b>
⊕ Padding	<b>(TBounds)</b>
⊕ Position	<b>(TPosition)</b>
ReadOnly	<b>False</b>
RotationAngle	<b>0</b>
⊕ RotationCenter	<b>(TPosition)</b>
⊕ Scale	<b>(TPosition)</b>
VarLink	None
VarType	<b>pstNone</b>
Width	<b>128</b>

Fig 151 TSMaster Panel control common properties

### 1.22.2.1.1 Align

Align controls docking feature of each panel control, the type of which is picked from the following list:

Value	Meaning
<b>Bottom</b>	<p>The control moves and pins to the bottom of its parent and resizes to fill the width of its parent. The height of the control is not affected. If another most side-pinned control already occupies part of the parent area, the control resizes to fill the remaining width of its parent.</p> <p>The anchors are set to [akLeft,akBottom,akRight].</p>
<b>Center</b>	<p>The control moves to the center of the parent area. The control's size is not affected. If another side-pinned control already occupies part of the parent area, the control moves to the center of the remaining parent area.</p> <p>The control is not anchored to its parent.</p>
<b>Client</b>	<p>The control resizes to fill the client area of its parent. If another side-pinned control already occupies part of the parent area, the control resizes to fit within the remaining parent area.</p> <p>The anchors are set to [akLeft,akTop,akRight,akBottom]</p>
<b>Contents</b>	<p>The control resizes to fill the entire bounds of its parent, overlapping it.</p> <p>The anchors are set to [akLeft,akTop,akRight,akBottom].</p>

<b>Fit</b>	<p>The control resizes to fit the parent area, preserving its aspect ratio. The control moves to the center of the parent area.</p> <p>The anchors are set to [akLeft,akTop,akRight,akBottom].</p>
<b>FitLeft</b>	<p>The control resizes to fit the parent area, preserving its aspect ratio. The control moves to and pins to the left side of the parent.</p> <p>The anchors are set to [akLeft,akTop,akRight,akBottom].</p>
<b>FitRight</b>	<p>The control resizes to fit the parent area, preserving its aspect ratio. The control moves to and pins to the right side of the parent.</p> <p>The anchors are set to [akLeft,akTop,akRight,akBottom].</p>
<b>Horizontal</b>	<p>The control resizes to fill the height of its parent. The width of the control is not affected. If another side-pinned control already occupies part of the parent area, the control resizes to fill the remaining height of its parent.</p> <p>The anchors are set to [akLeft,akRight].</p>
<b>HorzCenter</b>	<p>The control is centered horizontally within the client area of the parent and resizes to fill the height of its parent. The width of the control is not affected. If another side-pinned control already occupies part of the parent area, the control resizes to fill the remaining height of its parent.</p> <p>The anchors are set to [akTop,akBottom].</p>
<b>Left</b>	<p>The control moves and pins to the left side of its parent and resizes to fill the height of its parent. The width of the control is not affected. If another side-pinned control already occupies part of the parent area, the control resizes to fill the remaining height of its parent.</p> <p>The anchors are set to [akLeft,akTop,akBottom].</p>
<b>MostBottom</b>	<p>The control moves and pins to the bottom of its parent, set to be the bottommost, and resizes to fill the width of its parent. The height of the control is not affected.</p> <p>The anchors are set to [akLeft,akRight,akBottom].</p>
<b>MostLeft</b>	<p>The control moves and pins to the left side of its parent, set to be the leftmost, and resizes to fill the height of its parent. The width of the control is not affected. If</p>

	<p>another most side-pinned control already occupies part of the parent area, the control resizes to fill the remaining height of its parent.</p> <p>The anchors are set to [akLeft,akTop,akBottom].</p>
<b>MostRight</b>	<p>The control moves and pins to the right side of its parent, set to be the rightmost, and resizes to fill the height of its parent. The width of the control is not affected. If another most side-pinned control already occupies part of the parent area, the control resizes to fill the remaining height of its parent.</p> <p>The anchors are set to [akTop,akRight,akBottom].</p>
<b>MostTop</b>	<p>The control moves and pins to the top of its parent, set to be the topmost, and resizes to fill the width of its parent. The height of the control is not affected.</p> <p>The anchors are set to [akLeft,akTop,akRight].</p>
<b>None</b>	<p>The control remains where it was placed. This is the default value. No automatic positioning and sizing are performed.</p> <p>The anchors are set to [akLeft,akTop].</p>
<b>Right</b>	<p>The control moves and pins to the right side of its parent and resizes to fill the height of its parent. The width of the control is not affected. If another side-pinned control already occupies part of the parent area, the control resizes to fill the remaining height of its parent.</p> <p>The anchors are set to [akRight,akTop,akBottom].</p>
<b>Scale</b>	<p>The control resizes and moves to maintain the relative position and size as its container resizes.</p> <p>The anchors are set to [akLeft,akTop,akRight,akBottom].</p>
<b>Top</b>	<p>The control moves and pins to the top of its parent and resizes to fill the width of its parent. The height of the control is not affected. If another most side-pinned control already occupies part of the parent area, the control resizes to fill the remaining width of its parent.</p> <p>The anchors are set to [akLeft,akTop,akRight].</p>
<b>VertCenter</b>	<p>The control is centered vertically within the client area of the parent and resizes to fill the width of its parent. The height of the control is not affected. If another side-</p>



	<p>pinned control already occupies part of the parent area, the control resizes to fill the remaining width of its parent.</p> <p>The anchors are set to [akLeft,akRight].</p>
<b>Vertical</b>	<p>The control resizes to fill the width of its parent. The height of the control is not affected. If another side-pinned control already occupies part of the parent area, the control resizes to fill the remaining width of its parent.</p> <p>The anchors are set to [akTop,akRight].</p>

### 1.22.2.1.2 Enabled

Controls whether the control responds to mouse, keyboard, and timer events.

Use Enabled to change the availability of the control to the user. To disable a control, set Enabled to False. Some disabled controls appear dimmed (for example: buttons, check boxes, labels), while others (container controls) simply lose their functionality without changing their appearance. If Enabled is set to False, the control ignores mouse, keyboard, and timer events.

To re-enable a control, set Enabled to True.

### 1.22.2.1.3 Height

Specifies the vertical size of the control (in pixels).

Use the Height property to read or change the height of the control.

### 1.22.2.1.4 Margins

Specifies the control's margins.

The Margins of a control are the distances (in pixels) from each edge (top, left, bottom, right) to another control within the same Parent or to the edge of its Parent. Margins adds space to the outer side of the control.

If a margin is not 0, no other control will come closer to the control than the specified distance. If the distance from a Parent edge to the corresponding control edge is smaller than the specified Margins for that edge, the control is repositioned

and resized, if necessary, to maintain the specified distance.

The following image shows how Padding and Margins properties affect alignment, position, and size of controls.




Fig 152 Margins description

#### 1.22.2.1.5 Opacity

Specifies the control opacity.

Set Opacity to customize the transparency of the current control.

Opacity takes values between 0 and 1. If Opacity is 1, the control is completely opaque; if it is 0, the control is completely transparent. The values over 1 are treated as 1, and the ones under 0 are treated as 0.

Opacity applies to the control's children.

#### 1.22.2.1.6 Padding

Specifies the control's padding.

The Padding of a control specifies how close, in pixels, the control's children can come to each of its edges (top, left, bottom, right). Padding adds space to the inner side of the control.

The control's children are repositioned and resized, if necessary, to maintain the Padding.

The above image in "Margins" section shows how Padding and Margins

properties affect alignment, position, and size of controls.

#### 1.22.2.1.7 Position

Specifies the upper-left corner of the current control, relative to its parent.

Position can be affected by the Padding of its parent and the Margins of the control.

#### 1.22.2.1.8 ReadOnly

Determines whether you can change the text of this edit control.

To prevent the contents of the edit control from being edited, set the ReadOnly property to True. Set ReadOnly to False to allow the contents of the edit control to be edited.

Setting ReadOnly to True ensures that the text is not altered, while still allowing you to select text. The selected text can then be manipulated by the application, or copied to the Clipboard.

#### 1.22.2.1.9 RotationAngle

Specifies the amount (in degrees) by which the control is rotated from the x-axis.

Positive angles correspond to clockwise rotation. For counterclockwise rotation, use negative values.

To set the rotation center, use RotationCenter as described below.

#### 1.22.2.1.10 RotationCenter

Specifies the position of the pivot point of the control.

The coordinates of the rotation center take values in the range from 0 through 1. The point with the coordinates (0,0) corresponds to the upper-left corner of the control, the point with the coordinates (1,1) corresponds to the lower-right corner of the control. The default center of rotation is (0.5, 0.5).

Values outside of [0,0] and [1,1] can be clipped in some descendant classes.

To set the rotation angle, use `RotationAngle` as described above.

### 1.22.2.1.11 Scale

Specifies the scale of the control.

Set the Scale coordinates to specify the scale on each axis.

The initial scale rate is 1 on each axis.

Note: Controls that have the `Align` or `Anchors` properties set can use a scale that is different from the default (1,1), so that controls align together even when they have a custom scale.

### 1.22.2.1.12 VarLink

The associated variable in TSMaster, which can be:

- CAN signal
- LIN signal
- System Variable

Normally you can double click on a control to change its associated variable, or just click the “...” button on the right side of property editor:



Fig 153 VarLink Editor

If your current control is associated with a CAN signal, then the popup dialog will prompt you to select a CAN signal from database:




Fig 154 CAN signal selector

If your current control is associated with a LIN signal, then the popup dialog will prompt you to select a LIN signal from database:




Fig 155 LIN signal selector

If your current control is associated with a system variable, then the popup dialog

will prompt you to select a system variable from the system variable manager:




Fig 156 System variable selector

Note: Some controls do not support associating with variables, such as groupbox, start-stop button and so on. In this case, the VarLink is not available.

Note: Default VarLink type is set to “None”, that is nothing is associated with the current control. If you want to assign this control with either CAN, LIN or system variable, please first modify the “VarType” property below.

### 1.22.2.1.13 VarType

Variable type of the current associated signal, which can be:

- None
- CAN signal
- LIN signal
- System variable

The default variable type of each control is “None”, you can switch type among the above types, by selecting the down arrow, or just double click the editor.




Fig 157 Switch signal type

### 1.22.2.1.14 Width

Specifies the horizontal size of the control (in pixels).

Use the Width property to read or change the width of the control.

### 1.22.2.1.15 TextSettings

Some text controls have this property, which provide all styled text representation properties and methods to manage them.

The styled text representation properties are FontColor, TextAlign, VertTextAlign, Trimming, WordWrap, and Font (TFont.Family, TFont.Size, and TFont.Style).

#### ■ FontColor

Specifies the font color of the text in this TTextControl control.

Use the FontColor property to read or change the font color of the text in this TTextControl control. The default value of the FontColor property is TAlphaColorRec.Black.

#### ■ TextAlign

Specifies how the text will be displayed in terms of horizontal alignment.

The TextAlign property specifies how the TTextControl object will display the text in terms of horizontal alignment. TextAlign can have one of the following values (defined in TTextAlign):

Center (default)--aligns the text on a horizontal axis, at the middle of the TTextControl object.

Leading--aligns the text on a horizontal axis, at the leftmost position inside the TTextControl object.

Trailing--aligns the text on a horizontal axis, at the rightmost position inside the TTextControl object.

#### ■ VertTextAlign

Specifies how the text will be displayed in terms of vertical alignment.

The VertTextAlign property specifies how the TTextControl control displays the text in terms of vertical alignment. VertTextAlign can have one of the following values (defined in TTextAlign):

Center (default)--aligns the text on a vertical axis, at the middle of the

TTextControl object.

Leading--aligns the text on a vertical axis, at the topmost position inside the TTextControl object.

Trailing--aligns the text on a vertical axis, at the bottommost position inside the TTextControl object.

#### ■ **Trimming**

Specifies the behavior of the text, when it overflows the area for drawing the text.

Trimming may take the following values defined in the TTextTrimming type: None, Character, and Word.

If the value of this property is not None and the text does not fit in the drawing area, then it is trimmed to fit the area and an ellipsis sign is printed after the trimmed text.

#### ■ **WordWrap**

Specifies whether the text inside the TTextControl object wraps when it is longer than the width of the control.

Set WordWrap to True to allow the TTextControl control to display multiple lines of text. When WordWrap is True, text that is too long for the TTextControl object wraps at the right margin and continues in additional lines.

Set WordWrap to False for the text to span onto a single line of the TTextControl. However, in this case, the text that is too long for TTextControl appears truncated.

The default value for the WordWrap property is False.

#### ■ **Font.Family**

Identifies the typeface of the font.

Use Family to specify the typeface of the font.

#### ■ **Font.Size**

The height of the font in points.

Use Size to specify the size of text. The size includes the ascent, above the baseline and the descent, below the baseline.

For example, suppose the font's Size is 24. On Windows, 24 DIPs is 24/96 or 1/4 inches tall. 1/4-inch on a screen at 96 DPI is 24 pixels.



Text sized in points on Windows will appear larger at the same numeric value. For example, 24 points at 96 DPI is 32 pixels tall.

■ **Font.Style**

Determines whether the font is normal, italic, underlined, and so on.

Use Style to add special characteristics to characters that use the font. Style is a set containing zero or more values from the following:

Table 3 Font style

Value	Meaning
<b>fsBold</b>	The font is bold.
<b>fsItalic</b>	The font is italic.
<b>fsUnderline</b>	The font is underlined.
<b>fsStrikeOut</b>	The font is displayed with a horizontal line through it.

1.22.2.2 Text

A text is used to display static text, or a signal real-time value (CAN, LIN, system variable). Text control has various properties, by modifying its properties, you can get sophisticated display effects as shown below:



Fig 158 Text control

Apart from the common properties described above, a text control has additional

6 properties:

Text	
Align	None
BkgdColor	<span style="border: 1px solid black; padding: 2px;">0E0E0E</span> ...
BorderActive	False
Enabled	True
Height	29
⊕ Margins	(TBounds)
Opacity	1
⊕ Padding	(TBounds)
⊕ Position	(TPosition)
ReadOnly	False
RotationAngle	0
⊕ RotationCenter	(TPosition)
⊕ Scale	(TPosition)
Text	Please select a
TextColor	<span style="display: inline-block; width: 1em; height: 1em; background-color: black; border: 1px solid black;"></span> clBlack
⊕ TextSettings	(TTextSettings)
Transparent	True
VarLink	LIN Signal
VarType	pstLINSignal
Width	200

Fig 159 Text additional properties

**BkgdColor:** the background color of a text. If the text is set to “Transparent”, this property does not have any effect.

**Border Active:** True: the border of the text is visible; False: the border of the text is invisible.

**Text:** the static text display for the end user. If “VarType” of the text is set to any signal besides “None”, the text control will display the signal value, and this text property does not have any effect.

**TextColor:** the color of the text.

**TextSettings:** Keeps the values of styled text representation properties that are set in the Object Inspector or programmatically.

TextSettings references a TTextSettings type object that handles values of styled text representation properties that are set in the Object Inspector or programmatically. TextSettings references a TTextSettings type object, which handles styled text representation properties to be used for drawing texts in this control.

TTextSettings type objects provide all styled text representation properties and methods to manage them.

The styled text representation properties are FontColor, TextAlign, VertTextAlign, Trimming, WordWrap, and Font (TFont.Family, TFont.Size, and TFont.Style).

Please refer to “TextSettings” section above to view detailed description.

### 1.22.2.3 Image

Image control displays static images for the end user. The most popular image types (png, jpg, bmp, gif, tif, tiff, ico) are all supported by the image control:




Fig 160 Image types supported

To change an image, just double click on the image control, you will see a picture selector popup dialog appears, from which you can load, save pictures to the image control:




Fig 161 Picture selector

The image control has two additional properties as shown below:

Align	None
Enabled	True
Height	27
⊕ Margins	(TBounds)
Opacity	1
⊕ Padding	(TBounds)
Picture <span style="color: red; font-weight: bold;">1</span>	(None)
⊕ Position	(TPosition)
ReadOnly	False
RotationAngle	0
⊕ RotationCenter	(TPosition)
⊕ Scale	(TPosition)
VarLink	None
VarType	pstNone
Width	200
WrapMode <span style="color: red; font-weight: bold;">2</span>	Fit

Fig 162 Image properties

#### ■ Picture

You can change the static image display by double-clicking the image, or by clicking the “...” button on the right side of this property.

#### ■ WrapMode

Specifies whether and how to resize, replicate, and position the bitmap image for rendering the TImage surface.

The WrapMode property should be one of the constants defined in the TImageWrapMode type:

**Original** displays the image with its original dimensions.

**Fit** provides the best fit, keeping image proportions (the ratio between the width and height) for the TImage rectangle. If needed, the image is scaled down or stretched to best fit the rectangle area. This is the default option.

**Stretch** stretches the image to fill the entire rectangle of the TImage component.

**Tile** tiles the TImage image to cover the entire rectangle of the TImage component.

**Center** centers the image to the rectangle of the TImage component. The image is never resized, regardless the size of the rectangle of the TImage component.

**Place** fits the image into the TImage rectangle. If the width or height of the image

is greater than the corresponding dimension of the TImage rectangle, then the image is scaled down keeping image proportions (the ratio between the width and height) to fit in the TImage rectangle. The obtained image is centered in the TImage rectangle. Place only makes images smaller, never larger.

#### 1.22.2.4 Group Box

Represents a graphical control used to arrange multiple related graphical controls on the surface of a form.

Use GroupBox whenever you need to arrange multiple related controls on a form (for instance, multiple radio buttons or check boxes). The most commonly grouped controls are radio buttons. After placing a group box on a FireMonkey form, select components from the Toolbox and place them in the group box. The Text property contains text that labels the group box at run time.




Fig 163 Group Box for grouped display of controls

Group box has two additional properties:




Fig 164 Group Box properties

#### ■ Color

The text color of group box.

#### ■ Text

The text display of group box.

### 1.22.2.5 Panel

Represents a generic general-purpose panel used to hold multiple controls for organizing purposes.

Use TPanel components when you need to provide the user with a way of placing multiple graphical components on a surface for organizing purposes.

Panels have methods to help manage the placement of child controls embedded in the panel. You can also use panels to group controls together, similarly to the way you can use a group box. Panels are typically used for groups of controls within a single form. Panels with no borders are useful as docking sites when writing applications that use drag-and-dock.

Panel has 12 additional properties compared with common properties of a standard control:




Fig 165 Panel additional properties

- [1] **ColorFill**: Determines the color used to fill the shape background.
- [2] **ColorStroke**: Determines the color of the drawing pen used to draw lines and shape contours of the graphical primitives.
- [3] **Corners**: Specifies shapes of which corners in the TRectangle rectangle object are customized according to the CornerType, XRadius, and YRadius properties.

By default, all four corners are customized.

Corners can contain a set of constants defined in the TCorner type: TopLeft, TopRight, BottomLeft, and BottomRight. Use the AllCorners constant to select all corners.

If Corners is an empty set or any of the XRadius and YRadius properties is zero, then no corner shape customization is used.

- [4] **CornerType**: Specifies the type of the corner shape's customization in the rectangle.

Values of CornerType are defined in TCornerType. These Round, Bevel,

InnerRound, and InnerLine values define the following types of corner shape customizations:




Fig 166 CornerType definition

CornerType applies to corners specified in the Corners set.

XRadius and YRadius specify the distance from a corner to the start point of the corner shape customization, on the horizontal and vertical sides.

Note: If Corners is an empty set or any of the XRadius and YRadius properties is zero, then no corner shape customization is used.

- [5] **FillActive:** Whether the current panel has fill property, if set to false, all properties related to fill have no effects.
- [6] **StrokeActive:** Whether the current panel has stroke property, if set to false, all properties related to stroke have no effects.
- [7] **StrokeDash:** Specifies the dash-dot style of lines or of contours.

A shape contour or a line can contain several segments (dash-dot groups) with different lengths and spaces between segments.

The possible values of Dash are Solid, Dash, Dot, DashDot, DashDotDot, and Custom defined in the TStrokeDash type.

The default is Solid--a single solid line.

Notice that if Dash is not Solid, Cap affects the ends of each line segment of the contour.

- [8] **StrokeThickness:** Specifies the width, in pixels, of the stroke outline to draw a line or a contour.



[9] **xRadius**: Specifies the distance from a corner to the start point of the corner shape customization, on the horizontal sides of TRectangle.

During design time, the maximum possible value of XRadius is limited by the half of the smallest side.

If XRadius=0, then no corner shape customization is used.

[10] **yRadius**: Specifies the distance from a corner to the start point of the corner shape customization, on the vertical sides of TRectangle.

During design time, the maximum possible value of YRadius is limited by the half of the smallest side.

If YRadius=0, then no corner shape customization is used.

### 1.22.2.6 Path Button

Path button is a push or checked button display complex images using vector graphic technology. You can pick a shape for a path button, and assign signals to it.




Fig 167 Path button

A path button also displays the state of the current signal. For example, we set the button's "ValueChecked" is 3, and "ValueUnchecked" is 2. Then the following behavior will be monitored:

- Associated signal is 3: the button will be displayed "Checked"
- Associated signal is 2: the button will be displayed "Unchecked"

- Associated signal is 1, or other value except 2 or 3: the button will be displayed “Unchecked”

A path button has additional 8 properties:

PathButton	
Align	None
ButtonShape <b>1</b>	Path Data (3857)
ButtonType <b>2</b>	pbtCheckButtc
ColorChecked <b>3</b>	☐ \$008080FF
ColorStroke <b>4</b>	☐ clBlack
ColorUnchecked	☐ clGray <b>5</b>
Enabled	True
Height	50
⊕ Margins	(TBounds)
Opacity	1
⊕ Padding	(TBounds)
⊕ Position	(TPosition)
ReadOnly	False
RotationAngle	0
⊕ RotationCenter	(TPosition)
⊕ Scale	(TPosition)
StrokeActive	False <b>6</b>
ValueChecked	1 <b>7</b>
ValueUnchecked	0 <b>8</b>
VarLink	None
VarType	pstNone
Width	100

Fig 168 Path button properties

### [1] Button Shape

The button shape is the data of its path, which represents a series of connected curves and lines. You can use the internal path selector to build the shape of the button, by clicking on the “...” button on the right side of the property.

There are in total 867 different paths in the list for you to choose from. If these shapes are not enough, you can add your own paths by clicking on the “Generate from Font...” button, to generate more paths from external font files:




Fig 169 Pick a path and select OK

Normally you can find more shapes in “Wingdings” or “Webdings” because they contain graphical symbols more than other font files:




Fig 170 Recommended font files for generating paths

After selecting proper font files, you can get more paths to select from:



Fig 171 External paths from font files

## [2] Button Type

A button type can be “Push button” or “Check button”:



Fig 172 Path Button type

**Push Button:** This button type has only one stable state “Unpushed State”. If you push this button down, it will enter “Pushed State”, and the signal associated with it will be changed to “ValueChecked”, but after you release your mouse, this button will revert back to “Unpushed State”, and the signal will be changed back to “ValueUnchecked”.

**Check Button:** This button type has two stable state “Unpushed State” and “Pushed State”. If you push this button, it will enter “Pushed State” and remain in this state even if you release your mouse. And if you push it again, it will switch back to “Unpushed State” and remain in this state.

## [3] ColorChecked

The path button will change its fill color to this color when the button is in “Pushed State”. Please use the color selector to assign a color to it:




Fig 173 Color Selector

**[4] ColorStroke**

Determines the color of the drawing pen used to draw lines and shape contours of the graphical primitives.

**[5] ColorUnchecked**

The path button will change its fill color to this color when the button is in “Unpushed State”. Please use the color selector to assign a color to it.

**[6] StrokeActive**

Whether the current button has stroke property, if set to false, all properties related to stroke have no effects

**[7] ValueChecked**

If the button is in “Pushed State”, its related signal will be changed to this value.

**[8] ValueUnchecked**

If the button is in “Unpushed State”, its related signal will be changed to this value.

### 1.22.2.7 Check Box

A check box is a value selector, which can be either ON(selected) or OFF(cleared).

- Check to set Gear to 1, uncheck to set Gear to 0
- Check to set Gear to 2, uncheck to set Gear to 0
- Check to set Gear to 3, uncheck to set Gear to 0

Fig 174 Check Box

A check box also displays the state of the current signal. For example, we set the check box's "ValueChecked" is 3, and "ValueUnchecked" is 2. Then the following behavior will be observed:

- Associated signal is 3: the check box will be automatically checked
- Associated signal is 2: the check box will be automatically unchecked
- Associated signal is 1, or other value except 2 or 3: the check box will be automatically unchecked

A check box has 4 additional properties:

CheckBox	
Align	None
Color	■ cBlack <b>1</b>
Enabled	True
Height	24
⊞ Margins	(TBounds)
Opacity	1
⊞ Padding	(TBounds)
⊞ Position	(TPosition)
ReadOnly	False
RotationAngle	0
⊞ RotationCenter	(TPosition)
⊞ Scale	(TPosition)
Text <b>2</b>	Check to set Gear t
⊞ TextSettings	(TTextSettings)
ValueChecked	1 <b>3</b>
ValueUnchecked	0 <b>4</b>
VarLink	CAN Signal
VarType	pstCANSignal
Width	290

Fig 175 Check box additional properties

#### [1] Color

The text color of check box can be set here.

#### [2] Text

The displayed text on the check box.

#### [3] ValueChecked

If the check box is checked, the associated signal will be changed to this value.

#### [4] ValueUnchecked

If the check box is unchecked, the associated signal will be changed to this value.

### 1.22.2.7.1 Track Bar

Track bar represents a general-purpose value changer for use in applications

where tracking is required.



Fig 176 Track Bar

A track bar also displays its associated signal value in real-time within its supported range. If its signal has a value that is out of the track bar's max range, then the track bar will display this signal value at its maximum range.

A track bar has 2 additional properties as shown below:

TrackBar	
Align	None
Enabled	True
Height	19
⊕ Margins	(TBounds)
Max	10000 <span style="color: red;">1</span>
Min	0 <span style="color: red;">2</span>
Opacity	1
⊕ Padding	(TBounds)
⊕ Position	(TPosition)
ReadOnly	False
RotationAngle	0
⊕ RotationCenter	(TPosition)
⊕ Scale	(TPosition)
VarLink	CAN Signal
VarType	pstCANSignal
Width	173

Fig 177 Track bar additional properties

The min and max properties specifies its associated signal's physical range.

### 1.22.2.8 Scroll Bar

A scroll bar Represents a standard value changer that is used to scroll the value range of a signal. Its performs completely same as "Track Bar" described above.

### 1.22.2.9 Input Output Box

An input output box is a text box to display or set signal value.



Fig 178 Input Output Box

An input output box has 3 additional properties:

InputOutputBox	
Align	None
Color <b>1</b>	clBlack
Enabled	True
Height	23
LabelWidth <b>2</b>	80
⊕ Margins	(TBounds)
Opacity	1
⊕ Padding	(TBounds)
⊕ Position	(TPosition)
ReadOnly	False
RotationAngle	0
⊕ RotationCenter	(TPosition)
⊕ Scale	(TPosition)
⊕ TextSettings	(TTextSettings)
Value <b>3</b>	Gear_2
VarLink	CAN Signal
VarName	Gear
VarType	pstCANSignal
Width	397

Fig 179 Input Output Box additional properties

### [1] Color

The text color of the text box.

### [2] LabelWidth

The width of its label in pixels.

### [3] Value

The signal's real-time value can be displayed or set here.





Note: The display of signal value supports symbol display. But setting value does not, because it is not easy sometimes for human to write complete symbol value for a signal without mistake, use physical value instead. Or if you want to set symbol value, please use "Value Selector".

## 1.22.2.10 Image Button

Image button displays a series of images depending on the real-time value of its associated signal. For example of the following value mapping:



Table 4 Image Button Value Mapping

Signal Value	Image
0	
1	
2	
3	

If its associated signal value is within [0, 1, 2, 3], this button will display the mapped image on the right side of the table. This image button will remain unchanged if its associated signal's value is out of scope of the value table [0, 1, 2, 3].

An image button has 5 additional properties as shown below:

ImageButton	
Align	None
Enabled	True
Height	100
Image <span style="color: red;">1</span>	(None)
ImageCount <span style="color: red;">2</span>	4
ImageIndex <span style="color: red;">3</span>	2
⊕ Margins	(TBounds)
Opacity	1
⊕ Padding	(TBounds)
⊕ Position	(TPosition)
ReadOnly	False
RotationAngle	0
⊕ RotationCenter	(TPosition)
⊕ Scale	(TPosition)
Value <span style="color: red;">4</span>	3
VarLink	CAN Signal
VarType	pstCANSignal
Width	100
WrapMode <span style="color: red;">5</span>	Fit

Fig 180 Image button additional properties

### [1] Image

The picture at the current "ImageIndex", click the "..." button on the right side of the property to change the current image.

### [2] ImageCount

The “Value - Image” pair count. Please set this count to a value between [1..100].

### **[3] ImageIndex**

The current editing image index from 0 to “ImageCount” - 1. If you want to set the first image, set this value to 0 and then modify “Image” property; If you want to set the last image (for example image count is 5 in total), set this value to 4 and then modify the “Image” property.

### **[4] Value**

The physical value of the current image index in “Value - Image” pair.

### **[5] WrapMode**

Specifies whether and how to resize, replicate, and position the bitmap image for rendering the TImage surface.

The WrapMode property should be one of the constants defined in the TImageWrapMode type:

**Original** displays the image with its original dimensions.

**Fit** provides the best fit, keeping image proportions (the ratio between the width and height) for the TImage rectangle. If needed, the image is scaled down or stretched to best fit the rectangle area. This is the default option.

**Stretch** stretches the image to fill the entire rectangle of the TImage component.

**Tile** tiles the TImage image to cover the entire rectangle of the TImage component.

**Center** centers the image to the rectangle of the TImage component. The image is never resized, regardless the size of the rectangle of the TImage component.

**Place** fits the image into the TImage rectangle. If the width or height of the image is greater than the corresponding dimension of the TImage rectangle, then the image is scaled down keeping image proportions (the ratio between the width and height) to fit in the TImage rectangle. The obtained image is centered in the TImage rectangle. Place only makes images smaller, never larger.

## 1.22.2.11 Selector

A selector is a “Text – Value” list, which represents a combo box, which is a button with a list box attached to it.

Click the button to display the list. You can select an item from the list and it will appear as the button's text. You can type text directly into the combo box button. For example, if you select “Gear\_2=2” in the list below, you will see the signal value associated to this selector changed to 2, You can also set “2” directly in the text area to force change the signal’s physical value to 2:




Fig 181 Selector

A selector has additional 3 properties as shown below:

Selector	
Align	None
Color	■ cBlack <b>1</b>
Enabled	True
Height	25
⊕ Margins	(TBounds)
Opacity	1
⊕ Padding	(TBounds)
⊕ Position	(TPosition)
ReadOnly	False
RotationAngle	0
⊕ RotationCenter	(TPosition)
⊕ Scale	(TPosition)
⊕ TextSettings	(TTextSettings)
ValueTable	(TStrings) <b>2</b>
VarLink	CAN Signal
VarName	Gear <b>3</b>
VarType	pstCANSignal
Width	398

Fig 182 Selector

### [1] Color

The text color of the selector.

### [2] Value Table

Value Table is a list of “Name - Value” pairs. By clicking on the “...” button, you can edit the pairs:




Fig 183 Value Table editor

Please be sure to follow the rules “Name=Value” while editing the value table.

### [3] VarName

The display name on the left side of the selector, which is automatically set by the signal selector when this control is associated with a signal, you can also modify this display name, too.

#### 1.22.2.12 Button

A button is a push button setting its associated signal when its state is “Pushed”, and never revert value when its state is “Unpushed”. It has only one trigger value:



Fig 184 Button

Please refer to “Path Button” with “Push Button” mode for details.

#### 1.22.2.13 Progress Bar

A progress bar represents an animated progress indicator for general progress indication. It is a display only control for signal physical value or system variable value

monitoring.



Fig 185 Progress Bar

A progress bar has 2 additional properties:

ProgressBar	
Align	None
Enabled	True
Height	16
⊕ Margins	(TBounds)
Max	10000 <sup>1</sup>
Min	0 <sup>2</sup>
Opacity	1
⊕ Padding	(TBounds)
⊕ Position	(TPosition)
ReadOnly	False
RotationAngle	0
⊕ RotationCenter	(TPosition)
⊕ Scale	(TPosition)
VarLink	CAN Signal
VarType	pstCANSignal
Width	301

Fig 186 Progress Bar additional properties

Min and Max specify the signal value range to display. In the above picture, the Min value is 0 and Max value is 10000. If the signal's actual value is 15000, the progress bar will remain display 100% value range.

#### 1.22.2.14 Radio Button

RadioButton, also called option button, presents a set of mutually exclusive choices. You can create individual radio buttons or use a group to automatically arrange radio buttons into groups. You can group radio buttons to let the user select one from a limited set of choices.




Fig 187 Radio Button

Radio button also displays the signal real-time value if the value matches its “ON state value”.

A radio button has 3 additional properties as shown below:

RadioButton	
Align	None
Color	clBlack
Enabled	True
GroupName	Group1
Height	21
⊕ Margins	(TBounds)
Opacity	1
⊕ Padding	(TBounds)
⊕ Position	(TPosition)
ReadOnly	False
RotationAngle	0
⊕ RotationCenter	(TPosition)
⊕ Scale	(TPosition)
SwitchValue	1
Text	Check to set G
⊕ TextSettings	(TTextSettings)
VarLink	CAN Signal
VarType	pstCANSignal
Width	180

Fig 188 Radio Button additional properties

### [1] Color

The text color of radio button.

### [2] GroupName

Specifies the name of the group this radio button is part of.

Set the GroupName property to the name of the group this radio button belongs to. If multiple radio buttons are part of the same group, that is, all of them have the same GroupName, when you click one of them, it becomes selected, while the others in this group become cleared.

### [3] SwitchValue

The SwitchValue will be written to the associated signal if the current radio button is checked. Besides, if the associated signal has been changed externally, this radio

button will also show a “checked” state.

### 1.22.2.15 Start Stop Button

Start stop button controls whether the current application should be connected or disconnected. There are no additional properties assigned with start stop button.

In editor mode, you can select this button and modify its common properties, as shown below:



Fig 189 Start Stop button in editor mode

If you switch the panel into test mode while the application is disconnected, you can see the selection border of this button disappears, that means you can click this button to bring the application into connected state.



Fig 190 Start Stop button in test mode

And after this button is clicked in test mode, you can see the application is connected, and this button switches to a “stop button” indicating that if you click this button again, the application will be disconnected.



Fig 191 Start Stop button in application connected state

### 1.22.2.16 Switch

Switch represents a two-way on-off switch for use in applications.

Use a Switch whenever you need to provide the user with a two-way on-off switch.




Fig 192 Switch

A switch also displays its associated signal's real-time value if the value matches its "ValueLeft" or "ValueRight" properties.

A switch has 2 additional properties as shown below.

Switch	
Align	None
Enabled	True
Height	30
⊕ Margins	(TBounds)
Opacity	1
⊕ Padding	(TBounds)
⊕ Position	(TPosition)
ReadOnly	False
RotationAngle	0
⊕ RotationCenter	(TPosition)
⊕ Scale	(TPosition)
ValueLeft	-20 <span style="color: red;">1</span>
ValueRight	120 <span style="color: red;">2</span>
VarLink	CAN Signal
VarType	pstCANSignal
Width	90

Text	Containers
Switch2	
<i>D/CAN_FD_Powertrain/Engine/EngineData/EngTemp</i>	

Fig 193 Switch additional properties

### [1] ValueLeft

This value will be written to its associated signal if you switch this control from right to left.

### [2] ValueRight

This value will be written to its associated signal if you switch this control from left to right.

## 1.22.2.17 LED

LED is a display only control to show Boolean value of a signal.

A led has 13 additional properties as shown below:






Fig 194 LED additional properties

**[1] ColorOFF**

The LED's fill color will be changed to this value if its associated signal's value is lower or equal than "ValueOFF".

**[2] ColorON**

The LED's fill color will be changed to this value if its associated signal's value is larger or equal than "ValueON".

**[3] ColorStroke**

The stroke color of the LED shape.

**[4] LEDType**

LED shape type, can be: Circle, Ellipse, Horizontal Line, Vertical Line, Rectangle, Round Rectangle, Pie

**[5] StrokeActive**

This property will control whether stroke related properties is activated.

**[6] StrokeDash**

Specifies the dash-dot style of lines or of contours.

A shape contour or a line can contain several segments (dash-dot groups) with different lengths and spaces between segments.

The possible values of Dash are Solid, Dash, Dot, DashDot, DashDotDot, and Custom defined in the TStrokeDash type.

The default is Solid--a single solid line.

**[7] StrokeThickness**

Specifies the width, in pixels, of the stroke outline to draw a line or a contour.

**[8] Text**

The display text on top of this LED.

**[9] TextActive**

This property controls the visibility of the display text.

**[10] TextColor**

The color of the display text.

**[11] TextHeight**

The height of the display text in pixels.

**[12] ValueOFF**

The LED's color will be switched to "ColorOFF" if its associated signal's value has been changed to this value.

**[13] ValueON**

The LED's color will be switched to "ColorON" if its associated signal's value has been changed to this value.

## 1.22.2.18 Page Control

### 1.22.2.18.1 Page Control Properties

Page control is a tab set that has the appearance of notebook dividers.

A page control has 3 additional properties as shown below:




Fig 195 Page Control

**[1] PageCount**

Specifies how many pages this page control holds. You must set a value between 1 and 100.

**[2] PageIndex**

This property will show the current page index starting from 0. If you want to edit the name of page 3, you must set "PageIndex" to 2 and then modify the "PageName" property.

**[3] PageName**

The name of the current page. If you want to modify the name of another page say the last page (5 pages in total), you must first set "PageIndex" to 2 and then modify this property.

**1.22.2.18.2 Delete a page in Page Control**

Steps to delete a page in page control:

- [1] Firstly, navigate to the page to be deleted, and delete all the controls in this page
- [2] Move the page to be deleted to the last page by setting "SetIndex" of the current page to the last index, if the count is 9, then the last index is 8
- [3] Decrement page count by 1

**1.22.2.19 Gauge**

Gauge displays a meter interface for monitoring signals or system variables. It is a display only control.

A gauge has 8 additional properties as shown below:




Fig 196 Gauge additional properties

**[1] AngleSpan**

The display area of this gauge from 0 ~ 360 degree:




Fig 197 Gauges with different angle spans

**[2] Color**

The text color of this gauge is controlled by this property.

**[3] IsCircle**

If this property is true, the gauge will be a circle, otherwise an ellipse.




Fig 198 Gauges with IsCircle set to true and false

**[4] MaxValue**

The maximum physical value of its associated signal.

**[5] MinValue**

The minimum physical value of its associated signal.

**[6] ShowBackground**

This property controls if a gauge's background color is visible.




Fig 199 Gauge with/without background

**[7] ShowValueMark**

This property controls if a gauge's value mark is visible.




Fig 200 Gauge with/without value mark

**[8] Text**

The display text on top of the gauge.

**1.22.2.20 Graphics**

Graphics is a curve container for multiple signals physical value display. You can add up to 100 signals into one graphics control. Graphics is a display only control.

A graphics control has 4 additional properties as shown below:




Fig 201 Graphics additional properties

**[1] EditSignalIndex**

This property determines which signal is currently being edited. If you want to modify the second signal's display name and database address, you should first set this property to 1 and then modify "VarLink" and "EditSignalName" properties.

**[2] EditSignalName**

Editing this property will update signal display name in “Lengend” area on the right side of the graphics control.

**[3] MaxPoints**

The maximum data points of each signal displayed in graphics control. The default point count is 1000.

**[4] SignalCount**

This property specifies the signal count inside this graphics control. If you want to add 5 signals into this control to display them, first set this property to 5, and then set “EditSignalIndex” from 0 to 4, during this process you can modify each signal’s property.

**1.22.2.21 Pie**

Pie control displays relationship of multiple signals. It is a display only control.

A pie control has 2 additional properties as shown below:




Fig 202 Pie additional properties

**[1] EditSignalIndex**

This property determines which signal is currently being edited. If you want to modify the second signal’s database address, you should first set this property to 1 and then modify “VarLink” properties.

**[2] SignalCount**

This property specifies the signal count inside this pie control. If you want to add 5 signals into this control to display them, first set this property to 5, and then set

“EditSignalIndex” from 0 to 4, during this process you can modify each signal’s property.

## 1.22.3 Panel Design Recommendations

### 1.22.3.1 Using Shortcuts

You can find shortcuts description in “Information” page of each Panel form.

Note: You must first select one or more panel controls and then press shortcuts, so that these shortcuts may affect the controls you selected.




Fig 203 Panel shortcuts

### 1.22.3.2 Remaining Bus Simulation

If any panel signal is associated with CAN or LIN signal, the CAN RBS or LIN RBS is forced to be started if it is not configured to be automatically run when application is started. This is because panel bus signals rely on “Remaining Bus Simulation” functionality.

## 1.23 Test System

TSMaster test system provides a complete solution for general purpose test automation requirements, which covers every aspect of automated tests.






Fig 204 TSMaster Test System

Please refer to TSMaster example “CAN Test Demo.T7z” to see the ability of Test System:







Fig 205 CAN Test Demo Example

### 1.23.1 Test System Toolbar

Test system toolbar provides one-key start feature of all test cases and report generation, which greatly improves test efficiency.



Fig 206 Test System Toolbar

-  Start all test cases required based on the test system configuration.
-  Stop the test system.
-  Start auto generation of test report.

### 1.23.2 Test System Overview

Test system overview displays the test system name, icon and descriptions of the current test system. You can create or open one test system at a time.




Fig 207 Test system overview

### 1.23.3 Test System Login

You must first login into the test system before any operation in the test system. The system will grant you abilities based on your current privileges. Note: the default user name and password for a new test system are all "admin", please type in the user name and password correctly in order to login. You can also tick "Remember" so that you do not need to type user name and password again the next time you use test system.




Fig 208 Test System Login

After successful login, you can see "System user management" under "System Login" panel if your privilege is "Developer":

Logged in as admin (Developer)

User Name:

Password:

Remember

Index	User Name	Password	Privileges
1	admin	*****	Developer
2	user	*****	User

Fig 209 System User Management

There are 3 user privileges as described below:

- **User:** Can only perform tests, user cannot edit test cases.
- **Administrator:** Can edit the whole test system except user list.
- **Developer:** Can edit every aspect of test system.

There are 5 buttons on bottom of the user management panel:

- **Add Button:** To add new user into the test system.

Add New User

User Name:

Password:

Confirm Password:

Privilege: 

- User (Lowest)
- Administrator (High)
- Developer (Highest)

Fig 210 Add new user

- **Delete Button:** To delete the selected user from the list. Note: If you delete all users from the list, you may not be able to login to the system next time. Please contact TOSUN if you are in this situation.
- **Edit User Button:** To open the edit user dialog box, the user name, password and user privilege can be modified.
- **Save Button:** Save the current list after modification.
- **Close Button:** Close the current panel after modification.

### 1.23.4 System Configuration

You can configure the test system, import or export the whole test system with its test cases and parameters from an external config file.

Note: users with “User” privilege are not able to edit the system configuration.




Fig 211 System Configuration

- **Test System Name:** the name of the current test system, which will appear in the test report.
- **Test System Description:** Enter the description of the current test system.
- **Test System Icon:** You can change the icon of the test system. All major image file types are supported.
- **Import Test System:** You can load the test system from an external file.
- **Export Test System:** You can export the whole test system to an external file.
- **Create New Test System:** This will delete everything in the current test system and create an empty one for you to configure.
- **Test System Directory:** You can open the test system directory.

### 1.23.5 DUT Configuration

You can create, edit or delete DUTs (Device Under Test) in the test system, assign photos to DUT, assign part number if DUT is a device in EOL test, add any information to the DUT which will be represented in test reports.

Note: users with “User” privilege can only modify “Part Number” in the DUT

configuration.




Fig 212 DUT Configuration

### ■ DUT Selector

You can select the DUT you want to test in the list.






Fig 213 DUT selector

If you want to add new DUT into the list, please click the add button  and assign a name to the new DUT.

If you want to delete the current DUT from the list, please click the delete button  so that the current DUT information will be removed.

If you want to clear all DUTs from the list, please click the delete all button .

### ■ Part Number

You can assign a part number to the current DUT, this result in the auto generated test result folder has a name suffix for you to identify, such as:


`\TestResults\CAN_Test_System_Demo\TC1005_PN54321`



Fig 214 DUT part number

## Information List


You can add, delete, insert information into the information list. Press “Down” key on the bottom line of the list to add a new item.



Name	Value
Manufacturer Name	TOSUN
Manufacturer Address	No. 4801 CaoAn Road
Version Number	V1.1

Fig 215 Append a new item into the list

Or you can press “Insert” key on one of the line in the list to insert a new item before the selected line.



Name	Value
Manufacturer Name	TOSUN
Manufacturer Address	No. 4801 CaoAn Road
Version Number	V1.1

Fig 216 Insert a new item

Or you can delete everything in a line to delete this information line.

### 1.23.6 Test Parameters

You can perform parameterised test in the test system by adding global parameters or DUT specific parameters in the “Test Parameters” list:

Global Parameters (All DUTs share the same parameters)					
Index	Type	Name	Value	Description	
1	s32	fps_1k_min	990	min frame rate in 1000 fps	
2	s32	fps_1k_max	1010	max frame rate in 1000 fps	
3	s32	std_data_id	123	identifier of standard data frame	
4	s32	ext_data_id	234567	identifier of extended data frame	
5	s32	std_remote_id	178	identifier of standard remote frame	
6	s32	ext_remote_id	7598125	identifier of extended remote frame	
7	s32	std_fd_id	456	identifier of standard fd frame	
8	s32	ext_fd_id	196183478	identifier of extended fd frame	
9	s32	fps_1k_min	1000	min frame rate in 1000 fps	

DUT Parameters (Different in each DUT)					
Index	Type	Name	Value	Description	

Fig 217 Test Parameters

A parameter supports the following data types:

- u8: unsigned char, 8 bits
- s8: signed char, 8 bits
- u16: unsigned word, 16 bits
- s16: signed word, 16 bits
- u32: unsigned integer, 32 bits
- s32: signed integer, 32 bits
- u64: unsigned long integer, 64 bits
- s64: signed long integer, 64 bits
- float: IEEE float, 32 bits
- double: IEEE float, 64 bits
- string: char array with terminator char “\0”
- TCAN: CAN data structure defined in mini program in “TSMaster.h”
- TCANFD: CAN FD data structure defined in mini program in “TSMaster.h”
- TLIN: LIN data structure defined in mini program in “TSMaster.h”

Please fill “Name”, “Value” and “Description” value after a new parameter is defined, as they may appear in the generated test code. The “Name” should strictly follow any C identifier’s rule.

After you open any of the test cases in test system, you can find the parameters you previously defined in the “Test Header”. For example, if you define a couple of test

parameters in “Global Parameters”, all these parameters are visible and are the same in all DUTs:




Fig 218 Auto generated parameter definitions

And you can also find the constant values of the parameters after the record definition:

```

26 #ifdef TSMP_IMPL
27 TGlobalParameters cGlobalParameters = {
28     990, // s32 fps_1k_min min frame rate in 1000 fps
29     1010, // s32 fps_1k_max max frame rate in 1000 fps
30     123, // s32 std_data_id identifier of standard data frame
31     234567, // s32 ext_data_id identifier of extended data frame
32     178, // s32 std_remote_id identifier of standard remote frame
33     7598125, // s32 ext_remote_id identifier of extended remote frame
34     456, // s32 std_fd_id identifier of standard fd frame
35     196183478, // s32 ext_fd_id identifier of extended fd frame
36     1990, // s32 fps_2k_min min frame rate in 2000 fps
37     2010, // s32 fps_2k_max max frame rate in 2000 fps
38     2990, // s32 fps_3k_min min frame rate in 3000 fps
39     3010, // s32 fps_3k_max max frame rate in 3000 fps
40     3990, // s32 fps_4k_min min frame rate in 4000 fps
41     4010 // s32 fps_4k_max max frame rate in 4000 fps
42 };

```

Fig 219 Auto generated parameter value

And If you specify a parameter in “DUT Parameters”, you can configure different values of such parameter in different DUT by switching “DUT Configuration”:



DUT Parameters (Different in each DUT)				
Index	Type		Name	Value
1	TCAN	<input type="button" value="v"/>	dut_specific	123

Fig 220 Parameter in DUT TC1001

DUT Parameters (Different in each DUT)				
Index	Type		Name	Value
1	TCAN	<input type="button" value="v"/>	dut_specific	456

Fig 221 Parameter in DUT TC1005

After you re-open the test case in test system, you can find all the DUT specific parameters are defined with different value specified:

```

47 PDUTParameters pDUTParameters = &cDUTParametersTemplate;
48 s32 vDUTIndex = -1;
49 TDUTParameters cDUTParameters_TC1005 = {
50     456 // TCAN Para0
51 };
52 TDUTParameters cDUTParameters_TC1001 = {
53     123 // TCAN Para0
54 };
55 PDUTParameters cDUTParameters[2] = {&cDUTParameters_TC1005,&cDUTParameters_TC1001};
56 #endif
57
58 extern PGlobalParameters pGlobalParameters;
59 extern PDUTParameters pDUTParameters;
60 extern PDUTParameters cDUTParameters[ ];
61 extern s32 vDUTIndex;
62

```

Fig 222 DUT specific parameters definition

If you want to access “DUT global parameters” in mini program, just use the struct pointer “pGlobalParameters”

If you want to access “DUT specific parameters” in mini program, just use the struct pointer “pDUTParameters”

You can export the definitions of parameters into an external csv file:

	A	B	C	D	E	F	G	H
1	1	s32	fps_1k_min	990	min frame rate in 1000 fps			
2	2	s32	fps_1k_ma:	1010	max frame rate in 1000 fps			
3	3	s32	std_data_id	123	identifier of standard data frame			
4	4	s32	ext_data_id	234567	identifier of extended data frame			
5	5	s32	std_remote	178	identifier of standard remote frame			
6	6	s32	ext_remote	7598125	identifier of extended remote frame			
7	7	s32	std_fd_id	456	identifier of standard fd frame			
8	8	s32	ext_fd_id	1.96E+08	identifier of extended fd frame			
9	9	s32	fps_2k_min	1990	min frame rate in 2000 fps			
10	10	s32	fps_2k_ma:	2010	max frame rate in 2000 fps			
11	11	s32	fps_3k_min	2990	min frame rate in 3000 fps			
12	12	s32	fps_3k_ma:	3010	max frame rate in 3000 fps			
13	13	s32	fps_4k_min	3990	min frame rate in 4000 fps			
14	14	s32	fps_4k_ma:	4010	max frame rate in 4000 fps			
15								

Fig 223 Exported parameters in csv file

### 1.23.7 Test Cases

#### 1.23.7.1 Test Cases Interface

Test cases are listed in this interface, which also shows last results of each test case execution. “OK” results are marked green color and “NOK” results are marked red color.

You can add, edit, delete unlimited number of test cases in the “Test Cases” page:




Fig 224 Test Cases

You can do any operation in the popup menu by right clicking on the test case list area.




Fig 225 Test case popup menu

### 1. Select Test Cases

Select test cases popup menu item has a sub menu as shown below:




Fig 226 Select Test Cases sub menu

- **Check Selected:** Check all selected test cases that can be batched run in the test execution.
- **Uncheck Selected:** Uncheck all selected test cases that will not be run in the test execution.
- **Invert Selection:** Invert the checked states of test cases so that the previously checked test cases will not be executed but previously unchecked test cases will be executed.
- **Check All:** Check all test cases that can be batched run in the test execution.
- **Uncheck All:** Uncheck all test cases so that no test cases can be performed. If there are many test cases, you can uncheck all and then check the items you want to execute in some cases.

- **Check NOK Test Cases:** Check the test cases that are marked as “NOK”, this is useful for you to perform tests on failed items.

2. Add a new test group

You can add an empty test group in the list, which may contain other test groups and test cases.

3. Add a new test case

You can add a new test case under any test group, but you cannot add it directly under another test case.

4. Add test group list...

You can add a list of test groups with just one command:




Fig 227 Add a list of test groups

Then you can add test cases into these newly added test groups:

Test Group 13	3	<input checked="" type="checkbox"/>	Test Group	1	
Test Group 14	4	<input checked="" type="checkbox"/>	Test Group	1	
Bit error in data frame	5	<input checked="" type="checkbox"/>	Test Group	1	
Stuff error for basic frame	6	<input checked="" type="checkbox"/>	Test Group	1	
Stuff error for extended frame	7	<input checked="" type="checkbox"/>	Test Group	1	
Stuff error for FD frame payload bytes	8	<input checked="" type="checkbox"/>	Test Group	1	
CRC error	9	<input checked="" type="checkbox"/>	Test Group	1	
Combination of CRC error and form error	10	<input checked="" type="checkbox"/>	Test Group	1	
Form error in data frame at CRC delimiter bi	11	<input checked="" type="checkbox"/>	Test Group	1	
Form error at fixed stuff bit in FD frames	12	<input checked="" type="checkbox"/>	Test Group	1	

Fig 228 Added test groups

5. Add test case list...

You can add a list of test cases in the selected test group, or directly on the root:




Fig 229 Add a list of test cases

Bus Load	2	<input checked="" type="checkbox"/>	Test Group	1	CAN frame transmis
<input checked="" type="checkbox"/> FPS at 1k	2.1	<input checked="" type="checkbox"/>	Test Case	1	test if frame rate ca
<input checked="" type="checkbox"/> FPS at 2k	2.2	<input checked="" type="checkbox"/>	Test Case	1	test if frame rate ca
<input checked="" type="checkbox"/> FPS at 3k	2.3	<input checked="" type="checkbox"/>	Test Case	1	test if frame rate ca
<input checked="" type="checkbox"/> FPS at 4k	2.4	<input checked="" type="checkbox"/>	Test Case	1	test if frame rate ca
<input checked="" type="checkbox"/> Bit error test in base format frame	2.5	<input checked="" type="checkbox"/>	Test Case	1	
<input checked="" type="checkbox"/> Bit error in extended format frame	2.6	<input checked="" type="checkbox"/>	Test Case	1	
<input checked="" type="checkbox"/> Stuff error test in base format frame	2.7	<input checked="" type="checkbox"/>	Test Case	1	
<input checked="" type="checkbox"/> Stuff error test in extended frame form.	2.8	<input checked="" type="checkbox"/>	Test Case	1	
<input checked="" type="checkbox"/> Form error test	2.9	<input checked="" type="checkbox"/>	Test Case	1	
<input checked="" type="checkbox"/> Acknowledgement error	2.10	<input checked="" type="checkbox"/>	Test Case	1	
<input checked="" type="checkbox"/> Form field tolerance test for FD frame ft	2.11	<input checked="" type="checkbox"/>	Test Case	1	

Fig 230 Test cases added under the selected group

## 6. Delete Selected

Delete the selected test cases

## 7. Delete all test cases

Delete all the test cases in the list

## 8. Edit test case...

Open C code editor to edit the logic of the current selected test case

## 9. Run Selected Only

Run only the selected test case, this is useful if you do not want to execute other test cases.

## 10. Import test cases...

Import test cases from external configuration file.

## 11. Export test cases...

Export the current test case list to an external configuration file, which can be loaded by test system from another TSMaster.

## 12. Clear Verdicts

To clear the test result verdicts:

Bus Load	2	
✓ FPS at 1k	2.1	
✓ FPS at 2k	2.2	
✓ FPS at 3k	2.3	
✓ FPS at 4k	2.4	

Fig 231 Before verdicts are cleared

Bus Load	2	
⊖ FPS at 1k	2.1	
⊖ FPS at 2k	2.2	
⊖ FPS at 3k	2.3	
⊖ FPS at 4k	2.4	

Fig 232 After verdicts are cleared

### 13. Reset sort order

To reset the ordering of test cases to initial state.

### 14. Compile Selected

Compile the selected test cases. TSMaster mini programs (\*.mp) files are generated, one test case one mp file. The test system will run on compiled mp files.

### 15. Compile All

Compile all test cases.

## 1.23.7.2 Ordering of test cases

You can use mouse to drag drop test cases or test groups to perform any ordering requirements.

Bus Load	2	<input checked="" type="checkbox"/>
✓ FPS at 1k	2.1	<input checked="" type="checkbox"/>
✓ FPS at 2k	2.2	<input checked="" type="checkbox"/>
✓ FPS at 3k	2.3	<input checked="" type="checkbox"/>
✓ FPS at 4k	2.4	<input checked="" type="checkbox"/>

Fig 233 Before drop: drag an item "2.2" before "2.1"

Bus Load	2	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> FPS at 2k	2.1	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> FPS at 1k	2.2	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> FPS at 3k	2.3	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> FPS at 4k	2.4	<input checked="" type="checkbox"/>

Fig 234 After drop: drag an item "2.2" before "2.1"

You can also drag a test case from one group and drop it in another group to append it at last.

Test Case Name	Identifier	Sel...
Frame Transmission	1	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> Std Data	1.1	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> Ext Data	1.2	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> Std Remote	1.3	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> Ext Remote	1.4	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> Std FD	1.5	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> Ext FD	1.6	<input checked="" type="checkbox"/>
Bus Load	2	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> FPS at 2k	2.1	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> FPS at 1k	2.2	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> FPS at 3k	2.3	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> FPS at 4k	2.4	<input checked="" type="checkbox"/>

Fig 235 Drag a test case to another group: before append

Frame Transmission	1	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> Std Data	1.1	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> Ext Data	1.2	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> Std Remote	1.3	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> Ext Remote	1.4	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> Std FD	1.5	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> Ext FD	1.6	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> FPS at 2k	1.7	<input checked="" type="checkbox"/>
Bus Load	2	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> FPS at 1k	2.1	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> FPS at 3k	2.2	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> FPS at 4k	2.3	<input checked="" type="checkbox"/>

Fig 236 Drag a test case to another group: after append

If you want to move a group or a test case to the end, please move up the end node:

Test Case Name	Identifier	Sel...
Frame Transmission	1	<input checked="" type="checkbox"/>
Bus Load	2	<input checked="" type="checkbox"/>
FPS at 1k	2.1	<input checked="" type="checkbox"/>
FPS at 3k	2.2	<input checked="" type="checkbox"/>
FPS at 4k	2.3	<input checked="" type="checkbox"/>

Fig 237 To move "Frame Transmission" to end, you should move "Bus Load" upwards

Test Case Name	Identifier	Sel...
Bus Load	1	<input checked="" type="checkbox"/>
FPS at 1k	1.1	<input checked="" type="checkbox"/>
FPS at 3k	1.2	<input checked="" type="checkbox"/>
FPS at 4k	1.3	<input checked="" type="checkbox"/>
Frame Transmission	2	<input checked="" type="checkbox"/>

Fig 238 After releasing mouse cursor, the "Frame Transmission" is at the bottom

### 1.23.7.3 Test Case List Column

The descriptions of each test case column is as follows:

Table 5 Test Case List Columns

Column Name	Description
<b>Test Case Name</b>	You can edit the test group name or test case name here, which will become the name of its associated mini program.
<b>Identifier</b>	Unique identifier of test group or test case, which is named automatically by the ordering of the test cases.  Note: this value is read only.
<b>Select</b>	Tick the checkbox to select the test case or group, which will be executed in the test run.
<b>Type</b>	Can be "Test Group" or "Test Case".  "Test Case" can be executed but can not contain other test cases or groups.  "Test Group" is container only, which cannot be executed.
<b>Execution Count</b>	You can specify how many times this test case is executed, the default count is 1.



<b>Description</b>	You can write comments of any test case or test group here.
--------------------	---

#### 1.23.7.4 Test Case Code in Mini Program

Test case is implemented in mini program, besides all available features of mini program engine, it can use additional “Test” features as described below:




Fig 239 Test case additional features

Test functions can be called within any test case to make verdicts or write test related outputs.

```

4 // wait frame rate stable
5 if (!app.check(app.wait(3000, "wait until fps is stable"))) return;
6 // get frames per second for 0x123
7 com.get_fps_can(0, 0x123, &fps);
8 log("FPS for 0x123 is %d", fps);
9 // check frame rate within range [min, max]
10 if (fps >= pGlobalParameters->fps_1k_min &&
11     fps <= pGlobalParameters->fps_1k_max){
12     test.write_result_value("fps_1k_result", fps, lv1OK);
13     test.set_verdict_ok("Frame rate at 1000 fps meets requirements");
14 } else {
15     test.set_verdict_nok("Frame rate at 1000 fps does not requirement");
16     test.write_result_value("fps_1k_result", fps, lv1Error);
17 }
18 test.write_result_value("fps_1k_min", pGlobalParameters->fps_1k_min);
19 test.write_result_value("fps_1k_max", pGlobalParameters->fps_1k_max);
20 // stop test
21 app.terminate_application();
22

```

Fig 240 Test functions are available to test cases

Parameters can also be inserted easily into you test case:




Fig 241 Test parameters can be inserted easily

### 1.23.8 Report Configuration

You can configure how to generate your own test report in this section:






Fig 242 Report Configuration

Table 6 Report Configuration Description

Item Name	Description
<b>Enable Test Log</b>	Test reports are generated based on test logs, you must first enable test log in order to generate reports.
<b>Test Log Files Location</b>	You can specify a location to save test logs.

	 Use the left pointer button to specify a new location for the test reports, and use the right folder button to open the folder you specified.
<b>Report File Type</b>	Can be “pdf”, “word” and “excel” 
<b>Report Template File</b>	You can specify a location for the report template file, which is used for the generation of each test report.
<b>Report Path</b>	You can specify the path storing the final test report. TSMaster report automation engine will automatically store the test report under this directory.
<b>Report File Name</b>	You can specify the file name of your final report here.
<b>Auto start generation on completion</b>	Tick this check box to allow automatic report generation after all test executions are completed.
<b>Auto show generation progress</b>	Tick this check box to allow automation Interfaces (Word or Excel) display their working progress on your desktop.
<b>Auto open report path after generation</b>	Tick this check box to automatically open the report directory after the test report is generated.
<b>Auto open report after generation</b>	Tick this check box to automatically open the report after its has been generated.

You have to configure this setting before you use the “Report Automation”.

### 1.23.9 Test Execution

The test execution page provides a real-time monitor for each test case being executed. The passed test cases will be marked green color and the failed test cases will be marked red color. During the execution of one test case, the real-time log information will be displayed and updated in “Information” column.




Fig 243 Test Execution

### 1.23.10 Test Logs

Test logs displays the log information output from mini program using the “test” APIs and the following log APIs:

- test\_log
- test\_log\_ok
- test\_log\_nok
- test\_logCAN




Fig 244 Test Logs

## 1.24 Mini Program Library

### 1.24.1 Mini Program Library Concept

Mini program library helps you to manage reusable executable packages in your TSMaster mini program environment. A mini program will become a library when it is loaded by the “Mini Program Library”, it will stay in background providing the following features:

- All step functions, message callbacks or key events of this mini program can be executed in background for automation:




Fig 245 Mini program library running in background

- Custom functions of this mini program can be used by other mini programs as their function library providers:




Fig 246 Mini program library as function providers for other mini programs

With the help of mini program library, modular design of test automation or simulation logics can be realized.

## 1.24.2 Mini Program Library User Interface

Mini program library user interface is described below:




Fig 247 Mini program library user interface

Table 7 Mini program library user interface description

Index	Element	Description
1	Load	To load a mini program (*.mp) or (*.dll) in the library
2	Unload Selected	Unload the selected mini program library from the list
3	Unload All	Unload all the mini program libraries
4	Show File	Open the directory containing the selected mini program
5	Run All	Run all the mini program in background, after mini program is running, its step function, message callbacks and key events are working as they are executed in C code editor
6	Stop All	Stop the execution of all the mini programs
7	Library file area	This list shows all the loaded mini program with their names, version and running state displayed
8	Library function list	This list shows all the custom functions provided by the selected mini program. These functions can be used in any of your mini program in C code editor

### 1.24.3 Mini Program Library Popup Menu

When you right click on the library file area, you can see the following popup menu appears:




Fig 248 Mini program library popup menu

Besides the same items appear in toolbars, you can run or stop selected mini programs separately by using “Run Selected” and “Stop Selected” if you do not want to run or stop all the mini program libraries in the list.

## 1.25 Diagnostics

TODO: coming soon...

## 1.26 Calibration







### 1.26.1 Calibration Introduction

### 1.26.2 Calibration Data Types

Calibration data types are summarized in the following table:

Table 8 Calibration data types

Icon	Description
	Normal measurement variable, read only
	Read/Write measurement variable
	Virtual measurement variable

	Array variable
	Characteristic variable
	Curve variable
	Map variable
	ASCII variable
	Axis points

## 1.27 System Variable Manager

### 1.27.1 System Variable Manager Introduction

All system variables (user defined or internal variables) are listed in “System Variable Manager”, you can use this manager to view, edit, or select specific system variables in measurement windows.




Fig 249 System Variable Manager

Please refer to TSMaster example “System Variables In Mini Program.T7z” and



“System Variables Plot.T7z”:





Fig 250 System Variables Management

### 1.27.2 Toolbar of System Variable Manager

The items in system variable manager toolbar are listed below:

Note: all these toolbar buttons operate only on user variables, and internal variables are not affected.

 Create a new system variable in user list. This will create a auto-renamed system variable and popup an system variable editor for you to edit its properties.




Fig 251 System variable editor

The items in the system variable editor are described below:

Table 9 System variable editor description

Item	Description
<b>Name</b>	The name of the system variable under its category as described below.
<b>Category</b>	The category of the system variable. Together with the name forms the complete name of the system variable. For example: <p style="text-align: center;"><i>Name = name1</i></p> <p style="text-align: center;"><i>Category = cat1</i></p> The complete name of this system variable is “cat1.name1”, and this complete name must be unique in all the system variable list.
<b>Comment</b>	You can write comments for the current system variable.
<b>Data Type</b>	All the supported data types are listed below, you can pick one of them in the combo box: <ul style="list-style-type: none"> <li>■ Int32</li> <li>■ UInt32</li> <li>■ Int64</li> <li>■ UInt64</li> </ul>

	<ul style="list-style-type: none"> <li>■ UInt8 Array</li> <li>■ Int32 Array</li> <li>■ Int64 Array</li> <li>■ Double</li> <li>■ Double Array</li> <li>■ String</li> </ul>
<b>Read Only</b>	Whether this variable is read only
<b>Minimum Value</b>	The minimum value of this variable if it is not array type
<b>Maximum Value</b>	The maximum value of this variable if it is not array type
<b>Current Value</b>	<p>The current value of this variable in text</p> <p>You can modify the system variable value here by directly typing the value representation</p>



Cut, Copy and Paste buttons. You can select on or multiple system variables and use these buttons to cut, copy or paste variables freely. Note: if the complete name of the pasted variable is the same with existing one, it will be automatically renamed to keep name uniqueness.



Import and Export buttons. You can import system variable list from external files, or export them to external files, which can be loaded by another TSMaster application.



Delete and Delete All buttons. Use these buttons to delete selected system variables, or to delete all of them.



Filter of all the system variables by any field: variable name, type, value, owner and comment.

While typing, the user list and internal list will be filtered to display variables that only contain the typed string in any field.




Fig 252 Filtering of System Variables

### 1.27.3 Popup Menu of System Variables

If you right click on the user list, you can see the following popup menu appears:




Fig 253 System Variables popup menu

1. Cut: Cut the selected user variables into clipboard
2. Copy: Copy the selected user variables into clipboard
3. Paste: Paste the selected user variables from clipboard in the user list
4. Create User Variable: Create a new user variable in the user list
5. Delete Selected: Delete the selected user variables from the user list
6. Clear All: Delete all the user variables

### 1.27.4 Working with System Variables

Please always use the complete name to identify any system variable. For example, if a system variable name is “Var1”, with its category named “Cat1”, please use “Cat1.Var1” to globally identify this system variable, since this complete name is unique in TSMaster.

## 1.28 Measurement Setup

Measurement Setup displays the data flow from data source to each measurement window. Apart from “Data Source”, each measurement window represents a node in the measurement setup. You can use drag and drop feature of this treeview to parameterize the measurement filter for data reduction.




Fig 254 Measurement Setup

Please refer to TSMaster example “Measurement Setup.T7z” to see how to arrange multiple layouts and windows:




Fig 255 Measurement Setup Example

### 1.28.1 Measurement Setup Toolbar



Auto zoom of the measurement treeview chart, if checked, the treeview will be fitted into the current display area:



Fig 256 Zoom to fit of Measurement Setup



If this button is unchecked, the treeview items will be displayed with their original size, and you can drag the horizontal or vertical scroll bars to view the whole treeview:




Fig 257 Measurement Setup without zoom support

Expand all or Collapse all buttons. Use these buttons to expand all the nodes of the measurement setup treeview, or to collapse all of them.

Reinitialize the struct button. Click this button to discard the current data reduction structure you just built and will result in the following plain display of treeview items:




Fig 258 Measurement Setup Structure re-initialized

Delete the selected window or delete all the measurement windows from memory.

### 1.28.2 Measurement Setup Popup Menu

If you right click on each of the node in the measurement setup treeview, you can see the following popup menu appears:




Fig 259 Measurement Setup Popup Menu

1. Open Selected: Show the selected window
2. Add Measurement Node: To add a measurement node from the sub-menu list as a child node after the selected node:




Fig 260 Add a measurement window as a child

3. Insert Measurement Node: To add a measurement node from the sub-menu list as a filter node in front of the selected node




Fig 261 Insert a measurement window before the selected node

4. Insert Filter



To insert a filter window before the selected node, the filter can be configured to filter the nodes after itself.




Fig 262 Insert a filter for the selected measurement node

#### 5. Rename

You can rename any measurement window so as to identify it easily in the future.

#### 6. Delete Selected

The selected node with its associated measurement window will be removed from memory.

#### 7. Sub-Menu for Measurement Window

You can pick an item to add or insert it into the measurement setup.

### 1.28.3 Working with Measurement Setup

#### 1.28.3.1 Measurement Setup Node State

There are 4 states of a measurement setup node:

##### 1. Deleted State




Fig 263 Measurement Window Deleted State

This means this window is removed from memory, the data flow is cut off and will not be transferred to its sub nodes. You can simply double click this delete node to

create it and show it again.

## 2. Feed Through State




Fig 264 Measurement Window Feed Through State

This state means the associated measurement window does not have any configured filter for its sub nodes. The data flows into this node and will directly flows out from this node without any filter and goes to its sub nodes.

## 3. Filter Applied State




Fig 265 Measurement Filter Applied State

This state means the associated measurement window has internal filter for the current window and also for the sub windows after it. For example, the following transmit window has three transmit messages:

CAN / CAN FD Transmit																	
Row	Send	Trigger	Message Name	Id	Chn	Type	DLC	BRS	D0	D1	D2	D3	D4	D5	D6	D7	Comment
1	▶	50 ms	EngineData	064	2	Std. Data	8	<input type="checkbox"/>	00	00	00	00	00	00	00	00	
2	▶	2 ms	Gateway_2	111	1	Std. Data	8	<input type="checkbox"/>	00	00	00	00	00	00	00	00	
3	▶	100 ms	Gateway_1	110	1	Std. Data	3	<input type="checkbox"/>	00	00	00						

Fig 266 Transmit window with 3 messages in the list

The measurement windows after this transmit window are automatically filtered to allow only three identifiers 0x64, 0x111 and 0x110 to be flowed into them.

## 4. Filter Blocked State




Fig 267 Measurement Window Filter Blocked State

This state means the current measurement window has built in filter, but the filter configuration does not allow any data pass it. In this case all the sub nodes after it will all be blocked and cannot receive any messages.

#### 5. Selected State




Fig 268 Measurement Window Selected State

This state means this measurement node is currently selected by user, you can remove it from memory, or to rename it, or to drag it to other measurement node as a child node.

### 1.28.3.2 Measurement Windows Filter Capabilities

The capabilities of each measurement window is listed below:

Table 10 Measurement Window Filter Capabilities

Measurement Window	Filter Capability
<b>Measurement Setup</b>	Feed Through
<b>Message</b>	Feed Through
<b>CAN / CAN FD Trace</b>	Built-In Filter in Trace
<b>LIN Trace</b>	Built-In Filter in Trace
<b>CAN / CAN FD Transmit</b>	The transmit messages act as filter
<b>LIN Transmit</b>	The messages in schedule table act as filter
<b>Graphics</b>	The added signal's message act as filter
<b>Gauges</b>	The added signal's message act as filter
<b>Statistics</b>	Feed Through
<b>CAN Database</b>	The messages in the loaded database (Channel specific) act as filter
<b>LIN Database</b>	The messages in the loaded database (Channel

	specific) as as filter
<b>Bus Logger</b>	Feed Through
<b>Bus Replay</b>	Feed Through
<b>System Variables</b>	Feed Through
<b>Panel</b>	The signals or messages in the panel act as filter
<b>C Code Editor</b>	The messages in the receive/transmit/pre-transmit callbacks act as filter
<b>CAN RBS Simulation</b>	The messages in the loaded database (Channel specific) act as filter
<b>LIN RBS Simulation</b>	The messages in the loaded database (Channel specific) act as filter
<b>Test System</b>	Feed Through
<b>Diagnostics Manager</b>	Feed Through
<b>Calibration Manager</b>	Feed Through
<b>System Information</b>	Feed Through
<b>Application Host</b>	Feed Through
<b>Automotive File Converter</b>	Feed Through

## 1.29 Measurement Filter

Measurement Filter Window is a universal filter for all kinds of bus signals.




Fig 269 Measurement Filter Window

Please refer to TSMaster example “Measurement Setup.T7z” to see how to use

measurement filter:





Fig 270 Measurement Setup Example

### 1.29.1 Measurement Filter Toolbar

 Measurement Filter global switch in ON state, which means the current filter is activated, which is performing filter functions for all the sub measurement windows:





Fig 271 Measurement Filter with activated state

 Measurement Filter global switch in OFF state, which means the current filter is deactivated, the data will be feed through this filter, all sub measurement windows will directly get the data.




Fig 272 Measurement Filter with deactivated state

Stop   Pass Pass Filter mode. This means data matches the items in the filter list will be passed to sub nodes, others will be blocked:




Fig 273 Measurement filter in pass filter mode

Stop   Pass Stop Filter mode. This means data matches the items in the filter list will be blocked, others will be passed to sub nodes:





Fig 274 Measurement Filter in stop filter mode



Add items sub menu, which has the following 6 menu

items:

- Add Any Frame

This means any frame will match this filter, in “Filter Pass Mode” every frame

will be passed by this filter, while in “Filter Stop Mode” every frame will be blocked by this filter.




Fig 275 Any Frame filter

- Add Single Raw ID

You can modify this filter to allow a specific identifier matches this filter.





Fig 276 Measurement Single Raw ID Filter

- Add Single Database ID

You can pick a an identifier from database by clicking on the  button of the following popup window:




Fig 277 Measurement Database Identifier

- Add Id Range

You can add “Identifier Range” to filter a range of specific identifiers by specifying the start and end identifiers. In the following filter configuration, the identifier range is 0x0 to 0x23, if any identifier is within this range, it will match this filter:




Fig 278 Measurement Filter of Identifier Range

- Add Database Node

You can add “Node” filter to allow a group of transmitting or receiving message that are associated with the specific node to be matched.

The direction of the messages in the node can also be modified as “Tx”, “Rx” or “Both Tx and Rx”:






Fig 279 Measurement filter of Node messages

#### ■ Add Error Frame

Error frames can also be matched by adding “Error Frame” filter. This is really useful in test situations.




Fig 280 Error Frame Filter in Measurement Filter

⬇ ⬆ Expand All and Collapse All

You can expand all channels to view details or collapse all of them.

✖ ✖ Delete selected or Delete All

### 1.29.2 Measurement Filter Popup Menu

If you right-click on the list of the filter window, you can see the following popup menu appears:




Fig 281 Measurement Filter Popup Menu

1. Add Any Frame: this filter will match any frame on Bus
2. Add Single Raw ID: this filter will match a single identifier
3. Add Single CAN Database ID: this filter will match a single identifier in CAN database
4. Add Single LIN Database ID: this filter will match a single identifier in LIN database
5. Add Id Range: this filter will match a range of identifiers specified by start and end identifiers
6. Add CAN Database Node: this filter will match a group of messages transmitted or received by the specified CAN node
7. Add LIN Database Node: this filter will match a group of messages transmitted or received by the specified LIN node
8. Add Error Frame: this filter will match error frames appear on Bus
9. Enable Selected: the selected filter items will be activated
10. Disable Selected: the selected filter items will be deactivated
11. Enable All: all filter items will be activated

12. Disable All: all filter items will be deactivated
13. Expand All: the treeview items will be expanded
14. Collapse All: the treeview items will be collapsed
15. Delete Selected: the selected filter item will be deleted
16. Delete All: all the filter items will be deleted

### 1.29.3 Filter List Operation

Items in the filter list can be dynamically switched to enabled or disabled state with a single mouse click even if the application is running. The filter behavior of the items will be affected immediately:




Fig 282 Enable or Disable filter items in runtime

## 1.30 Document

Document window can be opened in Project page of main ribbon:






Fig 283 Document Window

You can write comments, descriptions and tutorials in the document with mixed text and images. You can create multiple documents in this window. The file format of the document is “.rtf”.

### 1.30.1 Document Toolbar


 Edit the current document in external program. If you click this button, a default program for editing “.rtf” file in your computer will be opened.


 Save the current document.

 Refresh the current document to the latest state. If this document file is modified by external program, use this button to refresh it.

 Open the directory containing the current document.

 Create a new document in the tabs.

 Delete the current document in this window. Note: this operation will not remove the rtf file from the disk.

 Delete all the documents in this window. Note: this operation will not remove the rtf files from the disk.

### 1.30.2 Document Area





Fig 284 Document Area

The top text box is used to make description of the current project document window. And the selection in this window will show different documents in tabs. You can add a tab by clicking  button and assign a name to the newly created document file.

### 1.30.3 Document Popup Menu




Fig 285 Document Popup Menu

1. Cut: Cut the selected text or images to clipboard
2. Copy: Copy the selected text or images to clipboard.
3. Paste: Paste clipboard contents to the text box area.
4. Increase Indent: Increase the indent count of the selected text lines.
5. Decrease Indent: Decrease the indent count of the selected text lines.
6. Font: You can assign font styles to the selected text block.
7. Paragraph: You can change the paragraph properties of the selected text blocks.
8. Bullets and Numbering: You can assign bullets or number prefixes to your selected text blocks.
9. Bookmark: You can add new bookmarks.
10. Hyperlink: You can assign hyperlinks to the text lines you selected.

### 1.31 LIN Remaining Bus Simulation

Similar to CAN Remaining Bus Simulation, please refer to “CAN Remaining Bus Simulation” chapter.

## 1.32 Automotive File Converter

Automotive File Converter is used to convert automotive database files from one format to another. This window can be opened in “Tool” page in the main ribbon:







Fig 286 Automotive File Converter

### 1.32.1 Automotive File Converter Toolbar

 Auto zoom of the converter treeview chart, if checked, the treeview will be fitted into the current display area.

 If this button is unchecked, the treeview items will be displayed with their original size, and you can drag the horizontal or vertical scroll bars to view the whole treeview.

 Auto open the directory containing the destination file. If a new file is converted, a directory containing this file is opened.

 Do not auto open the directory containing the destination file.

### 1.32.2 Supported input files

The following inputs files are currently selected (continuously growing):




Fig 287 Supported source file type

You can select one of them from the list, and you will see the treewiew containing the supported output file types on the right will be synchronized to the file type you selected:




Fig 288 Select a source file type first

### 1.32.3 Supported output files

Source file should be assigned before double clicking on the right nodes of exported file type.

The supported file types are listed below:

Table 11 Automotive File Converter Output Matrix

Output\Input	DBC	ARXML	Xlsx	Xls	DBF	YAML	SYM
DBC		●	●	●	●	●	●

<b>ARXML</b>	●		●	●	●	●	●
<b>Xlsx</b>	●	●		●	●	●	●
<b>Xls</b>	●	●	●		●	●	●
<b>CSV</b>	●	●	●	●	●	●	●
<b>Json</b>	●	●	●	●	●	●	●
<b>DBF</b>	●	●	●	●		●	●
<b>YAML</b>	●	●	●	●	●		●
<b>SYM</b>	●	●	●	●	●	●	
<b>FIBEX</b>	●	●	●	●	●	●	●
<b>C Source</b>	●						

Note: Xlsx and xls file are format specific. If you want to import Xlsx or xls files, you should make sure the formats are correct. You can get the template by simply convert any dbc to Xlsx and start working on such file.

#### 1.32.4 Steps to Convert Database Files

- Select a source file type

for example, if we want to convert a dbc file to excel, you should first select “dbc” format in the left list:




Fig 289 Select source file type

- Select a source file to input by double clicking on the “Source Node”






Fig 290 Load an input file

- Double click the “xlsx” icon on the right tree, a “Save” dialog will popup for you to specify the destination file you want to save.




Fig 291 Convert to xlsx file

- Finally, you will get the destination file

Frame Name	Launch Type	Launch Parameter	J1939 Byte No.	J1939 Bit No.	Signal Name	Signal Function	J1939 Length [bit]	J1939 Default	J1939 Not Available	Recorder	Engine	Torque	Value	Name / Phys. Range	Function / Increment Unit
0xh VECTOR_INDEPENDENT_SIG	0	NoMsgSendType	0	1	EngInjectionVol		64	0	i	s			0.0		
64h EngineData	#	NoMsgSendType	0	17	EngTorque		64	0	i	s			0.0		
				2	IdleRunning		1	0	i	s			0	Running	
				3	EngTemp		7	0	i	s			1	Idle	
				26	ShiftRequest		1	0	i	s			0	Shift_Request_Off	
													1	Shift_Request_On	
				26	SleepInd		1	0	i	s			0.0		
				27	EngTubePressure		64	0	i	s			0.0		
				4	PetrolLevel		8	0	i	s			0.255	l	
				35	EngValvePos		64	0	i	s			0.0		
				43	EngStates		64	0	i	s			0.0		
				51	EngIgnitionAngle		64	0	i	s			0.0		
				6	EcoMode		2	0	i	s			0.0		
				6	Gear		3	0	i	s			0	Idle	
													1	Gear_1	
													2	Gear_2	

Fig 292 The destination file is generated

### 1.32.5 Steps to Convert dbc file to C Code

- Select dbc source and assign a dbc file as the steps above
- Double click on the “C Source Code” node, then you are asked to save a C Source file with the same name of the dbc file




Fig 293 Save C Source File

After C source file is saved, another save dialog is popped up for header file storage, this is because this conversion generates two files for C code source and header, you can save it to the same directory:




Fig 294 Save C Header File

- You can find these files in the directory you specified

名称	大小	修改日期	类型
can_fd_powertrain.c	60 KB	2020/10/17 星期六 11:19	Notepad++ Doc...
can_fd_powertrain.h	56 KB	2020/10/17 星期六 11:19	Notepad++ Doc...

Fig 295 C Code generated by dbc

### 1.33 Symbol Mapping

### 1.34 Stimulation

### 1.35 Calibration Curve

### 1.36 Video Replay

### 1.37 Excel Test Module



## Chapter 2 TSMaster Help Files

### 2.1 Help Content

TSMaster help content can be accessed in the application button of TSMaster main interface:




Fig 296 TSMaster Help Contents